

HF HOOKER ASSEMBLY INSTRUCTION 7228-55038 99 Icohor

7228-55038-99 Jacher Entertainment Credenza

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.


Read all instruction and study the drawing carefully before starting the assembly process.


HARDWARE PACK

NO	SKETCH	DISCRIPTION	QTY.
Α		ANTI-TIP KIT	1pc

PART LIST

NO	SKETCH	DISCRIPTION	QTY.
1		REMOVABLE SHELF	3 pcs





NOTE: ADJUST LEVELER IF NEEDED TO LEVEL **CABINET ON UNEVEN FLOOR.**

NOTE:

Anti tipping kit restraint is provided. please follow the instruction enclosed with the pack



ASSEMBLY INSTRUCTION

7228-55038-99 Jacher Entertainment Credenza

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process.

INSTRUCTION FOR HINGE ADJUSTMENT

(If necessary, the door panels by adjusting the set screw on the door hinges as needed.)

