



# USER GUIDE – LED LIGHTED MIRROR



IF IN DOUBT ABOUT FITTING THIS PRODUCT, PLEASE CONSULT A QUALIFIED ELECTRICIAN

COMPONENT PARTS AND FITTINGS



**Mirror**



**Screw & Wall plug x 4**  
(Included in pack)



**Wire nut x 3**  
(Included in pack)

**Suggested Tools:**



**Screw driver**



**Drill**

**Safety Warning**

**Safety:**



- We suggest you spend a short time reading the instruction leaflet.
- Carefully check that you have all the parts before beginning assembly.
- Keep small parts and fittings out of children's reach and keep children well away from construction area, as the unassembled product contains small parts, which could present a choking hazard.
- We suggest you retain these instructions for future reference.
- This appliance can be used by adults ONLY.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

**Caution:**



- In order to avoid overheating, do not cover the mirror.
- Switch off the mains supply and remove the appropriate fuse or switch off the appropriate circuit breaker before commencing installation
- Make sure that there is no danger that the cord or extension cord is inadvertently be pulled or cause anyone to trip when in use.

Please read all instructions carefully. Before you proceed to install, make sure that the power supply is turned off and remains off until installation is complete.



Please note that each part has been assigned a number and proceed in a numerical order.



STEP3. Connect to the main supply





STEP4. Hang up the Mirror on the wall



Touch switch

Press once to change color temp. and on-off.  
Press and hold switch for dimming the lumens.



A (inch)	B (inch)	C (inch)	Hanged Vertically		Hanged Horizontally		LED length/in	Driver
			D (inch)	E (inch)	F (inch)	G (inch)		
18	30	1.93	16.55	23.94	28.55	11.94	61.42	35W
18	36	1.93	16.55	29.94	34.55	11.94	73.62	35W
20	30	1.93	18.55	23.94	28.55	13.94	66.14	28W
20	36	1.93	18.55	29.94	34.55	13.94	78.74	50W
20	40	1.93	18.55	33.94	38.55	13.94	85.83	50W
24	30	1.93	22.55	23.94	28.55	17.94	73.62	35W
24	36	1.93	22.55	29.94	34.55	17.94	85.83	50w
24	40	1.93	22.55	33.94	38.55	17.94	93.70	50W
27	30	1.93	25.55	23.94	28.55	20.94	79.13	50W
27	36	1.93	25.55	29.94	34.55	20.94	91.34	50W
27	40	1.93	25.55	33.94	38.55	20.94	99.21	50W
30	30	1.93	28.55	23.94	28.55	23.94	85.85	50W
30	36	1.93	28.55	29.94	34.55	23.94	99.21	50W
30	40	1.93	28.55	33.94	38.55	23.94	105.91	50W
30	48	1.93	28.55	41.94	46.55	23.94	122.83	75W
30	72	1.93	28.55	65.94	70.55	23.94	169.69	100W
36	36	1.93	34.55	29.94	34.55	29.94	228.35	50W
36	40	1.93	34.55	33.94	38.55	29.94	118.11	75W
36	48	1.93	34.55	41.94	46.55	29.94	131.50	75W
36	60	1.93	34.55	53.94	58.55	29.94	157.48	75W
36	72	1.93	34.55	65.94	70.55	29.94	181.89	100W
42	60	1.93	40.55	53.94	58.55	35.94	169.29	100W
42	72	1.93	40.55	65.94	70.55	35.94	194.09	100W