




Randburg

Models: KBF524C KBF524SS


KBF524ORB KBF524MB


Karran USA Tel: 866.452.7726 www.karran.com info@karran.com



- 1. Handle
- 2. Rubber Washers
- 3. Clamps
- 4. Mounting Nuts
- 5. Mounting Screws
- 6. Clamp Springs
 - 7. Quick Connect
- 8. Clip
- 9. Faucet Body
- 10. O-ring
- 11. Rubber Washer
- 12. Clamp
- 13. Nut
- 14. Aerator Wrench
- 15. Allen Key
- 16. Handle
- 17. Drain
- 18. Supply Lines


TECHNICAL DRAWING






1. Position the o-ring (#10)and faucet body (#9) in the installation surface as shown and secure it with the rubber washer (#11) and clamp (#12) and tighten the nut (#13) with adjustable wrench.

STEP 2




2.Position handle mounting (#1,#16) in installation surface as shown and secure it with kit (#2,#3,#4,#5) and tighten the screws with screwdriver. Repeat the above stepsfor the other handle.




3. Connect the "quick connect" hose (#7) to the handle (#1 and #16) and faucet body (#9). Insert the clip (#8) to the part on the "quick connect" hose. You will hear a "click" when it has been successfully connected. Use the provided clamps (#6) to secure the ends of the "quick connect" hose.

STEP 4




4.Connect the water supply lines to the bottom ends of the "quick connect" hose (#7) and to the hot and cold water supply valves. Secure and tighten with an adjustable wrench.
Caution: Be careful not to mix up the hot and cold supply lines.
Check all connections (shown with arrows in the image) for leaks.
Re-tighten if necessary. Do not over tighten!

STEP 5




5.Place a bead of silicone or plumbers putty as shown on the drain opening of the sink. Thread the top (1 2) into the drain. Secure the drain by tightening the nut (3) underneath the sink.

STEP 6




6.Insert drain stopper ④ into the drain. On the underside of the sink.

STEP 7




7.On the underside of the sink, ensure the ball rod (#42) is inserted through the drain stopper base hole. See diagram for visual.

STEP 8




8. Place one end of the spring clip (#45) on the end of the ball rod (#42). Insert the ball rod through the hole on the lift rod strap (#43), then slide the other end of the spring clip (#45) over the ball rod (#42). See diagram for visual.

STEP 9



9.Insert the lift rod (#44) through the pop-up hole on the faucet. Underneath the sink insert the lift rod (#44) through the lift rod strap (#43). Tighten the thumb screw on the lift strap.Note: be sure to ensure there is enough room to lift the lift rod up and down to open and close the drain.


STEP 10




10. Remove the aerator with an aerator wrench (a quarter or flat surface tool could also work). Turn the faucet handle all the way on, turn on the hot and cold water supply and flush water lines for one minute. Reinstall the aerator with an aerator wrench.

OPERATION

How to operate the handle:



REPLACEMENT PARTS



No.	Description	Finish/Color	Item No.
43	Lift Rod Strap		51NGM231A
44	Lift Rod		50NG18202
45	Spring Clip		53NGM231A
46	O-ring		84NGM23A
47	Drain		C11011
48	Supply Lines		G08603SR

*Denotes faucet component color options:

C - Chrome

SS - Stainless Steel

ORB - Oil-Rubbed Bronze

MB - Matte Black

	No.	Description	Finish/Color C,SS,OEB	Item No.
	1	Handles	MB	50P00CV22
	2	Wearing Rings	C,SS,OEB	81P24BW73
	3	Handles	MB	51P00CV22
	4	Screws		8EM5X5RB
	5	O-rings		8J152X16
	6	Adapters		52P20CV13
	7	Screws		8RM4X15A
	8	Lock Nuts		5YG1B277
	9	O-rings		8J42X2
	10	Cartridge		K5B2320DQ
	11	Inlets		8JG94015
	12	O-rings		8J14X2A
	13	Underbodys		50T94019DQ
	14	O-rings		8J23X2A
	15	O-rings		8J22X205A
	16	Rubber Washers		81N94015
	17	Clamps		80N94015
	18	Mounting Nuts		8NM94015
	19	Mounting Screws		8RM6X15
	20	Clamp Springs		81T94015
	21	Upper Shell	C,SS,OEB	50T1B412
	22	Screws	MB	8RM4X4
	23	Bottom Shell	C,SS,OEB	51T1B412
	24	Water Way	MB	52T1B412
	25	Screws		8RM4X8
	26	O-ring		8J46X2
	27	Aerator		80M24123NP1
	28	O-ring		8J16X2A
	29	Inlet		8JG18U24DQ
	30	O-rings		8J11X2A
	31			81N18U24
	32	Rubber Washer		
	_	Clamp		80N18U24
	33	Nut		8NM16X15
	34	Connection Hose		GKJ390HM0
	35	Clip	C,SS,OEB	8ST56226
	36	Cartridge	MB	K5B232ZDQ
	37	Diverter Cover		50D2B412
	38	O-ring		8J6X15
	39	Lift Rod		50NG18202
	40	Allen Key		8BS25
	41	Aerator Wrench		80P00013
	42	Ball Rod		82NGM23A