
KINGSTON

INSTALLATION INSTRUCTIONS Angle Stop

Instructions:

- 1. Place nut (3) and ring (2) on tube (1).
- 2. Insert tube (1) into valve.
- 3. Wrench tighten nut (3) onto valve.
- 4. Connect hose (4) to the valve body (5).
- 5. Stop any leaks by tightening nuts slightly.



www.kingstonbrass.com

TOLL-FREE CUSTOMER SERVICE: 1-877-2-KBRASS

TECHNICAL SUPPORT E-mail: service@kingstonbrass.com

12775 Reservoir Street, Chino, CA 91710