


**KitchenAid®**

**30" SLIDE IN GAS CONVECTION RANGE**

**MODELS:**

KSGB900EBL0 (Black)  
KSGB900EWH0 (White)  
KSGB900ESS0 (Stainless)


# COOKTOP PARTS



# COOKTOP PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6	7101P485-60	Screw, Anti-Tip Kit	18	W10645947	Grommet
	W10665256	Instructions, Installation	7		Knob	19	W10664705	Bumper
	W10722060	Guide, Use & Care		W10579760	Stainless (All except Left Front)	20		Console, Lower Panel
	W10665227	Sheet, Tech		W10579761	Stainless (Left Front)		W10555932	Black
	W10703182	Wire Diagram					W10555933	White
	9762761	Tips, Safe Cooking (English)	8		Kit, Grate		W10555934	Stainless
	W10065852	Tips, Safe Cooking (French)		W10432520	Black	21	W10606241	Bracket, Anti-Tip
	W10400066	Guide, Quick Start (English)	9	3196169	Screw	22	W10162253	Brace, Corner (Left)
	W10400067	Guide, Quick Start (French)	10	W10289170	Support, Cooktop (Left)		W10162252	Brace, Corner (Right)
2		Kit, Burner Cap		W10289169	Support, Cooktop (Right)	23	W10555923	Bracket, User Interface
	W10479989	Black	11	8016P022-60	Glide, Main Top	24	W10598048	Bracket, Console (Center)
3		Console	12		Endcap	25	W10757531	Keypad, Shield
	W10697322	Black		W10555936	Black (Left)			FOLLOWING PARTS NOT ILLUSTRATED
	W10697323	White		W10555935	White (Left)		W10580232	Harness, Main
	W10697324	Stainless		W10555937	Stainless (Left)		W10754419	Harness, Bake/Broil
4	W10256028	Spreader, Flame (Right Front)		W10555939	Black (Right)		W10598169	Harness, Display
	W10256025	Spreader, Flame (Right Rear & Center)		W10555938	White (Right)		W10580265	Harness, Bake/Warm Drawer
	W10464795	Spreader, Flame (Left Rear)		W10555940	Stainless (Right)		W10575120	Harness, Keypad
	W10495853	Spreader, Flame (Left Front)	13		Trim, Vent		313438	Clip, Harness
5		Cooktop		W10577781	Black		3196520	Clip, Wire
	W10536181	Black		W10636527	White		W10580229	Wire, Ground
	W10536182	White		W10577782	Stainless		W10716764	Insulation, Burner Box
	W10588278	Stainless	14	W10453984	Control MRC2		W10701082	Insulation, Vent Trim
			15	W10603094	Assembly, Display			
			16	W10558372	Bracket, Control			
			17		Bezel			
				W10785119	Stainless			


# CHASSIS PARTS



# CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10614920	Assembly, Flue	24	W10273192	Rod, Door Switch	47	W10162249	Cover, Wire
2	9758701	Spacer, Door	25	W10624590	Cord, Power	48	W10162241	Channel, Rear
3	W10273002	Bracket, Oven Support	26	W10035900	Support, Oven Bottom	49	W10813366	Shield, Wire
4		Panel, Side	27	W10541959	Shield, Bake	50	W10686408	Kit, Reservoir (Steam Rack)
	W10162245	Black	28	W10454648	Assembly, Light	51		The wireless meat probe is a licensed product and covered by the manufacturer total replacement warranty. If the customer has any questions or concerns regarding the accessory please have them call KitchenAid Customer Satisfaction Center toll-free at 1-800-541-6390 or visit our web site at <a href="http://www.KitchenAid.com">www.KitchenAid.com</a> . No warranty claims will be paid for the wireless meat probe or will this be a service part.
	W10575396	White	29	311255	Bulb, Oven Light			INSULATION
5	W10162259	Assembly, Cooling Fan	30	W10341186	Assembly, Front Foot	W10289173		Insulation, Wrap
6	W10627802	Switch, Door	31	W10390007	Assembly, Base Rail (Right)	W10162240		Insulation, Back
7	W10554006	Rack, Maximum Capacity		W10390008	Assembly, Base Rail (Left)	4820F015-59		Insulation, Strap
8	W10554008	Rack, Sliding	32	W10558276	Box, Burner	7111P017-60		Clamp, Wire
9	W10289077	Receiver, Hinge	33	W10617484	Assembly, Convection			
10	W10058460	Foot, Leveling	34	W10346153	Baffle, Full Convection			
11	W10211368	Bottom, Oven	35	W10362924	Screw			
12	W10586204	Sensor	36	W10554007	Rack, Steam			
13	3601P356-45	Baffle, Bake Burner	37	W10137382	Clip, Panel			
14	3196178	Screw	38	W10457998	Module, Spark (0+2)			
15	W10552502	Element, Broil Assist	39	W10475149	Module, Spark (5+0)			
16	W10311326	Assembly, Flue (Upper)	40	W10655451	Guard, Splash			
17	W10362924	Screw	41	W10162254	Duct, Cooling			
18	W10323077	Diffuser, Flame	42	W10162255	Duct, Cover			
19	3196178	Screw	43	W10273204	Pan, Bake			
20	W10289166	Back, Main	44	W10289168	Box, Burner			
21	W10162385	Gasket, Door	45	W10162257	Duct, Cooktop			
22	W10031780	Screw	46	W10289172	Cover, Back			
23	W10603482	Rack, Ladder						


# MANIFOLD PARTS



# MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10673618	Screw	8	W10566057	Valve, Gas (Right Rear & Center)	17	W10434277	Orifice (Right Front)
2	W10552120	Assembly, Orifice (Right Front)		W10566062	Valve, Gas (Right Front)		W10657949	Orifice (Right Rear)
	W10552119	Assembly, Orifice (Right Rear)		W10566055	Valve, Gas (Left Rear)		W10256132	Orifice (Left Front)
	W10552121	Assembly, Orifice (Left Rear)		W10432224	Valve, Gas Duel (Left Front)		W10566082	Orifice (Left Front)
	W10552122	Assembly, Orifice (Left Front)	9	W10224921	Bracket, Aegis		W10657947	Orifice (Center)
	W10552124	Assembly, Orifice (Center)	10	W10439242	Burner, Broiler		W10515054	Orifice (Left Rear)
3	W10295996	Bracket, Saddle Valve	11	W10680035	Burner, Bake	18	3196178	Screw
4	W10432252	Tube, Gas Supply	12	W10554066	Valve, Regulator	19	3196385	Screw
5	W10432517	Harness, Switch Spark	13	W10324262	Igniter, Bake	20	3400016	Screw
6	W10496872	Electrode (Right Rear)	14	W10306050	Tubing (Broiler Fitting To Valve)	21	3601P336-45	Baffle, Broil Burner
	W10496870	Electrode (Right Front & Center)	15	W10583216	Fitting, Broil Burner	22	W10575401	Clip, Spring Electrode
	W10464799	Electrode (Left Rear)	16	W10333842	Electrode, Broil	23	W10140571	Seal, Switch Shaft
	W10496874	Electrode (Left Front)				24	W10762686	Bracket, Manifold Support Following Parts Not Illustrated
7	W10475026	Assembly, Manifold					W10681410	Kit, LP Conversion  (Burners)
							W10566535	Kit, LP Conversion (Bake/Broil )

# DOOR PARTS






# DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10541911	Bracket, Glass Upper Handle
2	8533988	Screw
3		Assembly, Outer Door
	W10634272	Black
	W10634273	White
	W10634271	Stainless
4	W10541882	Liner, Door
5	W10541888	Glass, Inner
6		Assembly, Door Handle
	W10551000	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10031780	Screw
8	W10541885	Support, Glass
9		Scoop, Door
	W10613791	Black
	W10613790	White
	W10551024	Stainless
10	W10388635	Hinge, Door (Active)
11	W10319024	Washer, Door
12	W10541883	Hinge, Support Rail
13	W10031790	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
14		Badge
	W10518672	Grey
15	W10327235	Screw

# DRAWER PARTS



# DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Assembly, Drawer Handle	8	W10634260	Enclosure, Warming	20	W10550985	Retainer, Side Insulation
	W10551000	Stainless	9	W10551025	Cover, Gas Valve	21	3196560	Screw
2	W10757442	Drawer, Bake	10	W10634259	Cover, Wire	22	W10602493	Rack, Bake Drawer
3	W10550987	Seal, Drawer	11	W10586204	Sensor	23	W10551011	Insulation, Bake Drawer Bottom
4		Panel, Drawer Front	12	W10541944	Element, Bake	24	W10655446	Shield, Corner
	W10541953	Black	13	W10551019	Cover, Side			FOLLOWING PARTS NOT ILLUSTRATED
	W10541952	White	14	3823F017-45	Spacer, Handle	W10550983		Insulation, Retainer Bake Drawer
	W10541954	Stainless	15	W10551018	Insulation, Drawer Front	W10541960		Insulation, Drawer Top
5	W10541946	Slide, Drawer (Left)	16	W10550982	Insulation, Drawer			
	W10541945	Slide, Drawer (Right)	17	W10541947	Panel, Front Inner			
6	W10327235	Screw	18	W10729897	Fuse, Thermal			
7	8533988	Screw	19	W10550984	Insulation, Drawer Side			

# OPTIONAL PARTS (NOT INCLUDED)

## REFINISHING MATERIAL

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

## INSULATION

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

## PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	511873	White Porcelain (2 oz.)

## PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	350939	Enamel, Black
	285006	Black
	350942	White Primer

## PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

## ACCESSORY PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	31463A	Protectant, Cooktop
	31605	Kit, Cooktop Care
	W10355016	Cleaner, Stainless Steel
	W10355051	Cleaner, Cooktop
	W10391473	Pad, Cooktop Cleaning
	W10355049	Wipes, Stainless Steel Cleaning
	W10355010	Cleaner, Kitchen & Appliance
	W10275756	Cleaner, Granite
	31617A	Cleaner, Grate & Drip Pan
	WA906B	Scraper, Cooktop
	242905	Kit, Canning Unit
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan & Roasting
	W10432545	Kit, Grill
	W10432544	Griddle
	W10432019	Alt Cleaning Kit Assembly, Trim (5/8")
	W10675026	Black
	W10675027	White
	W10675028	Stainless (1 1/8")
	W10731886	Black
	W10731885	White
	W10731887	Stainless Assembly, Backsplash
	W10655449	Black
	W10655448	White
	W10655450	Stainless