


KitchenAid®

**1.9 CUBIC FOOT MICROWAVE HOOD
(Sensor Convection)**

MODELS:

KMHC319EWH0 (White)
KMHC319EBL0 (Black)
KMHC319ESS0 (Stainless)

CONTROL PANEL PARTS




CONTROL PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10652354	Installation Instructions
	W10644753	Use and Care Guide
	W10644756	Quick Reference Guide
	W10644755	Tech Sheet

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2		Cover, Control
	W10571112	White
	W10478239	Black
3	W10533504	Duct, Cooling Front
4	W10540727	Background, Control

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10536071	Microcomputer
6	W10540721	Seal, Control

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10540731	Lens
2	W10557532	Control
3	W10478216	Holder, UI
4	W10540298	Plate, UI Insulation
5	W10617743	Cover, UI
6	W10476546	Bracket, Door
7	W10604264	Assembly, Handle
8	W10540736	Cushion, Handle
9		Cover, Screw
	W10571119	White
	W10478657	Black
10		Bracket, Outer Door
	W10571118	White
	W10478656	Black

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10568846	Body, Door (With Glass)
12	W10489272	Hooks, Door
13	W10542546	Cover, Screw
14		Frame, Back Decorating
	W10570992	White
	W10476550	Black
15	W10643448	Stopper, Door
16	W10478653	Frame, Inner
17		Assembly, Door Frame
	W10688547	White
	W10688548	Black
	W10688550	Stainless
18	W10688552	Glass, Door
19	W10478659	Holder, Door Cable

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
20	W10508745	Wire, Door Control Cable
21	W10518673	Black
22	W10478230	Bracket, Door Cable
23	W10509362	Cable, Sensor
24	W10478647	Plate, Steam Protection
25		Door, Complete
	W10710350	White
	W10710351	Black
	W10710352	Stainless


INTERIOR AND VENTILATION PARTS



INTERIOR AND VENTILATION PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10540723	Chassis	15	W10536989	Thermistor PCBA	30	8206223	Clip
2	W10208564	Lamp, Halogen	16	W10510235	Tube, Smart Pop Sound	31	W10508748	PCBA, Smart Pop
3	W10525853	Terminal, Smart Pop	17	W10510234	Terminal, Smart Pop	32	W10631701	Magnetron, Air Guide
4	W10535950	Filter, Grease	18	W10568805	Resistor, Cement	33	W10536556	Motor, Cooling
5	W10571126	Plate, Bottom	19	W10211974	Switch, Micro	34	W10533503	Wheel, Cooling Fan
6	W10240330	Assembly, Lamp Glass and Holder	20	W10245194	Holder, Fuse	35	W10533486	Valve, Door
7	W10510237	Spacer, Smart Pop	21	W10138793	Fuse	36	W10533501	Housing, Cooling Fan
8	W10269457	Microswitch	22	W10591803	Thermostat, Magnetron	37	W10533502	Cover, Cooling Fan
9	W10269458	V15T16-CZ200/NC/NO Microswitch	23	W10709970	Transformer, High Voltage	38	W10533480	Holder, NTC
10	W10156812	V15T16-CC200/NC Spring, Interlock	24	W10518719	Bracket, Capacitor	39	W10458325	Actuator
11	W10156811	Plate, Cam	25	W10561770	Capacitor, High Voltage	40	W10533107	Deflector, Air
12		Support, Interlock	26	W10575765	Diode, High Voltage	41	W10571453	Insulation, Side
	8206419	Top	27	W10510233	Terminal, PCBA Smart Pop	42	W10540718	Bracket, Cavity
	W10156813	Bottom	28	W10259248	Cover, Thermostat			
13	W10197758	Assembly, Piston	29	W10599629	Thermostat, Convection			
14	W10605897	Capacitor, Hood Motor						


AIR FLOW PARTS



AIR FLOW PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10631698	Deflector, Air	11	W10557537	Sensor, Convection	19	W10533483	Duct, Cavity (Rear)
2	8206382	Cover, Lamp	12	W10210878	Holder, Lamp Cavity	20	W10627070	Duct, Cavity (Front)
3	W10557536	Sensor, Humidity	13	W10632409	Baseplate, Air Guide			(For White Models)
4	4393681	Lamp, Cavity 30 Watt	14	W10533484	Cover, Duct (Right)		W10570209	Duct, Cavity (Front)
5	W10533487	Plate, Air Guide	15	W10531156	Board, Filter			(Black and Stainless Models)
6	W10479847	Motor, Fan	16	W10139750	Socket, Motor Wire	21	W10629803	Shield, Finger (Includes Seal)
7	W10556824	Housing, Damper	17	W10533112	Outlet, Cavity (Back)	22	W10531724	Glass, Lamp
8	8206230	Filter, Charcoal	18	W10626122	Magnetron	23	W10652714	Assembly, Air Guide Grill
9	W10571180	Seal, Foam						
10	W10654514	Thermostat, Cavity						

TURNTABLE PARTS




TURNTABLE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10533498	Cover, Waveguide
2	W10626726	Hook, Microwave (Left Front & Right Front)
3	W10660052	Steamer
4	W10531726	Turntable

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10570257	Ring, Turntable
6	W10337248	Driver, Turntable
7	W10466420	Motor, Turntable
8	W10637931	Rack, Microwave
9	8184109	Seal, Waterproof

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
10	W10440082	Rack, Convection
11	W10568148	Seal, Turntable Block
12	W10573936	Hook, Microwave (Left Rear & Right Rear)

CABINET AND INSTALLATION PARTS



CABINET AND INSTALLATION PARTS

Illus.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10440498	Plate, Mounting
2	8206442	Damper
3	W10654511	Cord, Power
4		Case, Outer
	W10571409	White
	W10571408	Black
5		Grille, Vent
	W10701700	White
	W10701701	Black
6	W10625423	Cover, Fan Motor
7	W10571554	Assembly, Convection Motor and Fan
8	W10533488	Duct, Cooling (Upper)
9	W10533489	Duct, Cooling (Bottom)
10	W10570212	Duct, Air Turntable Motor
11	W10596040	Assembly, Mounting Nut
		Following Parts Not Illustrated
	W10571450	Insulation, Back
	W10571451	Insulation, Top
	W10571454	Insulation, Bottom
		Miscellaneous
	W10728970	Hardware, Installation
	W10190018	Template, Upper
	8169704	1/4-20x3" Panhead Screw
	W10622246	Harness, Main
	W10530090	Harness, Headlamp and Turntable
	W10539840	Harness, PCBA Ground Wire
	W10508741	Wire, Door Control Cable
	W10566563	Harness, Smart Pop
	W10566562	Cable, Fade In / Fade Out
	W10670896	Harness, Fade In / Fade Out