



KitchenAid®

24" ELECTRIC DOUBLE WALL OVEN

MODELS:

KODC304EBL00 (Black)
KODC304EWH00 (White)
KODC304ESS00 (Stainless)

CONTROL PANEL PARTS




CONTROL PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10758300	Guide, Use & Care
	W10758285	Instructions, Installation
2		Assembly, Control Panel Skin
	W10702189	Black
	W10704698	White
	W10704699	Stainless
3	W10752316	Assembly, Display

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10721210	Control
5		Assembly, Membrane
	W10694995	Black
	W10694996	White
6	3400832	Screw (Black)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10794084	Fuse, Thermal
		FOLLOWING PARTS NOT ILLUSTRATED
	W10691762	Harness, Main
	W10691785	Harness, Door Latch
	W10409840	Harness, EOL (MRC)
	4450800	Screw, Grounding
	4448664	Clamp, Conduit
	4451761	Support, Wiring
	4455191	Plate, Blower Service

OVEN PARTS




OVEN PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	8285593	Cover, Connector
2		Trim, Side
	W10756501	Black (Left)
	W10756502	Black (Right)
	W10756497	White (Left)
	W10756498	White (Right)
	W10144986	Stainless (Left)
	W10144985	Stainless (Right)
3	4455605	Receiver, Hinge (Left)
	4455606	Receiver, Hinge (Right)
4	W10105790	Bumper & Screw
5	4449845	Support, Bracket
6	8302347	Divider, Center Vent
7	W10784377	Chassis, Top
8		Deflector, Vent Box
	4455807	Black
	W10145009	Stainless
9	4452158	Tube, Vent
10	W10169756	Lens, Light

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
11	W10307114	Assembly, Oven Light
12	W10169757	Bulb, Light
13	3400832	Screw (Black)
14	9760754	Frame, Front
15	4455380	Gasket, Door
16	8281236	Screw
17	4449743	Screw
18		Assembly, Bottom Vent Trim
	W10339572	Black
	W10339573	White
	W10144973	Stainless
19	4451476	Support, Insulation
20	4451605	Cap, Spacer
21	4450582	Rail, Side (Left)
	4450581	Rail, Side (Right)
22	W10195934	Latch, Motorized
23	4449040	Screw
24	4448444	Grommet, Mounting Rail
25	W10782197	Side, Chassis

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
26	W10784207	Back, Chassis
27		Liner, Oven (Not serviceable)
28	4452152	Bracket, Bottom Vent
29	W10622170	Probe, Sensor
30	4449154	Screw
31	4449748	Screw
32	4450038	Screw
33	4451747	Cover, Back
34	W10358914	Trim, Center
35	4450118	Nut
36	W10774836	Thermostat
37	4450525	Base, Chassis
38	7101P426-60	Screw
39	4448933	Retainer, Gasket
		FOLLOWING PARTS NOT ILLUSTRATED
	4449314	Insulation, Wrap
	4450363	Insulation, Back


TOP VENTING PARTS



TOP VENTING PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	4451758	Block, Foam	4	4452365	Cover, Top Front	10	4450549	Cover, Top Rear
2	4451759	Vent, Exhaust	5	7101P426-60	Screw	11	9759135	Back, Control
3	W10016550	Blower (45MM) (Lower)	6	8302390	Bracket, Support Air Stop	12	4451598	Side, Control Top (Left)
	W10176670	Blower (65MM) (Upper)	7	4448664	Clamp, Conduit		W10755214	Side, Control Top (Right)
			8	4455178	Elbow, Top Vent	13	4448547	Vent, Control Panel
			9	4455177	Elbow, Bottom Vent			


OVEN DOOR PARTS



OVEN DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8303698	Liner, Door	11	W10708952	Bracket, Handle	18	4457112	Shield, Heat Bottom
2	9760572	Hinge, Door (Left)	12		Assembly, Door	19	4457101	Shield, Heat
	9760571	Hinge, Door (Right)		W10692493	Black			
				W10692494	White			
3	4449247	Glass, Inner		W10692415	Stainless			
4	4451720	Insulation, Door	13		Assembly, Door Handle			
5	4457130	Retainer, Glass		W10737395	Stainless			
6	7101P426-60	Screw	14		Clip Retainer			
7	9759223	Glass, Inner		W10789034	Black			
8	4448520	Bumper, Door		W10789033	White			
9		Badge		W10789032	Stainless			
	W10518672	Grey (Lower Door Only)	15	9759229	Bracket, Side			
			16	9759230	Bracket, Central			
10	8533988	Screw	17	3400832	Screw (Black)			

INTERNAL OVEN PARTS



INTERNAL OVEN PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10685631	Element, Broil	6	4455035	Tray, Hidden Bake	10	W10722667	Fan, Convection
2	9760769	Element, Convection	7	4450039	Cover, Hidden Bake Tray	11	W10631503	Blade, Fan
3	W10696057	Stone, Baking	8	7101P426-60	Screw	12	W10631504	Nut, Acorn
4	4448716	Rack, Oven	9	4449154	Screw	13	W10160821	Cover, Fan
5	W10207398	Element, Bake (Hidden)						

OPTIONAL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		Optional Parts
		PAINT, SPRAY
	350930	White
	261900	Citrine White
	830864	Black
		ADHESIVE
	591014	Adhesive, Loctite
	482338	Sealer, Silastic
		ACCESSORIES
	W10355049	Wipes, Stainless Steel Cleaning
	W10355016	Cleaner, Stainless Steel
	W10355010	Cleaner, Kitchen & Appliance
	W10275756	Cleaner, Granite
	4396923	Broiler Pan and Grid