


KitchenAid®

24" ELECTRIC BUILT-IN WARMING DRAWER

MODELS:

KOWT104ESS00 (Stainless)

CONTROL PANEL AND DRAWER PARTS




CONTROL PANEL AND DRAWER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10713340	Guide, Use & Care
	W10064720	Sheet, Tech
	W10713339	Instructions, Installation
2	8273277	Rack, Warming Drawer
3	W10162376	Slide, Vent
4	W10306304	Panel, Front
5	W10164996	Gasket, Drawer

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
6	9763127	Assembly, Drawer
7	W10480830	Screw
8	W10685897	Skin, Drawer
9		Assembly, Handle
	W10737395	Stainless
10		Badge
	W10518672	Grey
11	4455984	Knob, Thermostat
12	W10489562	Light, Indicator

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
13	4456314	Lens, Indicator
14	W10409136	Rail, Pan
15	9763125	Grip, Vent
16	W10035910	Magnet
17	4456861	Spacer, Lens
18	4456862	Clip, Lens Retainer
19	3823F017-45	Spacer, Handle

INTERNAL WARMING DRAWER PARTS



INTERNAL WARMING DRAWER PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10684521	Wrapper
2	313806	Screw
3	W10188461	Assembly, Slide
4	W10299387	Wall, Cavity (Left)
	9762307	Wall, Cavity (Right)
5	7101P309-60	Screw
6	W10121337	Control
7	W10117362	Gasket, Control

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
8	9763126	Fuse, Thermal
9	9763122	Enclosure, Electric
10	9763121	Cover, Enclosure
11	W10117363	Gasket, Enclosure
12	W10751754	Element, Heating
13	3196537	Screw
14	W10118049	Seal, Heating Element
15	W10118113	Seal, Switch

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
16	W10118073	Shield, Heat
		FOLLOWING PARTS NOT ILLUSTRATED
	W10129043	Harness, Main
	W10129023	Cord, Power
	W10131847	Sensor, Sealed
	4452601	Relief, Strain
	3400015	Screw, Grounding