




**30" 4 BURNER DOWNDRAFT DUAL FUEL
SLIDE-IN RANGE**

MODELS:

KSDG950ESS0 (Stainless)

COOKTOP PARTS




COOKTOP PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10787365	Installation Instructions
	W10750372	Use and Care Guide
	W10665227	Sheet, Tech
	W10750129	Wiring, Diagram
	9762761	Tips, Safe Cooking (English)
	W10065852	Tips, Safe Cooking (French)
	W10400066	Guide, Quick Start (English)
	W10400067	Guide, Quick Start (French)
2		Set, Burner Cap
	W10300347	Black
3		Console
	W10697329	Stainless
4	W10256028	Spreader, Flame (Left Front & Right Front)
	W10256025	Spreader, Flame (Right Rear)
	W10256024	Spreader, Flame (Left Rear)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5		Cooktop
	W10536175	Stainless
6	7101P485-60	Screw, Anti-Tip Kit
7		Knob
	W10579760	Stainless
8		Grate, Set
	W10752103	Black
9	3196169	Screw
10	W10289170	Support, Cooktop (Left)
	W10289169	Support, Cooktop (Right)
11	W10432544	Griddle
12		Endcap
	W10555937	Stainless (Left)
	W10555940	Stainless (Right)
13		Trim, Vent
	W10636529	Stainless
14	W10658111	Control MRC2
15	W10603096	Assembly, Display
16	W10558372	Bracket, Control
17		Bezel
	W10785119	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
18	W10645947	Grommet
19	W10664705	Bumper
20		Console, Lower Panel
	W10555934	Stainless
21	W10606241	Bracket, Anti-Tip
22	W10162253	Brace, Corner (Left)
	W10162252	Brace, Corner (Right)
23	W10555923	Bracket, User Interface
24	W10598048	Bracket, Console (Center)
25	W10757531	Keypad, Shield
		FOLLOWING PARTS NOT ILLUSTRATED
	W10580237	Harness, Main
	W10598169	Harness, Display
	W10575120	Harness, Keypad
	313438	Clip, Harness

CHASSIS PARTS




CHASSIS PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10289077	Receiver, Hinge
2	3196560	Screw
3		Panel, Side
	W10162245	Black
4	3400029	Nut
5	W10162385	Gasket, Door
6	W10544952	Element, Broil
7	W10774342	Element, Bake
8	W10362924	Screw
9	W10613792	Assembly, Flue
10	W10289168	Box, Burner
11	W10341186	Assembly, Front Foot
12	W10067840	Screw
13	W10541959	Shield, Bake
14	W10137382	Clip, Panel
15	W10390008	Assembly, Base Rail (Left)
	W10390007	Assembly, Base Rail (Right)
16	W10058460	Foot, Leveling
17	3196548	Fuse, Thermal
18	3196172	Screw
19	W10035900	Support, Oven Bottom
20	3186034	Bracket, Service
21	W10246624	Block, Terminal
22	W10162247	Main, Back Downdraft
23	3196178	Screw
24	W10454648	Assembly, Light
25	311255	Bulb, Oven Light
26	3400016	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
27	W10586204	Sensor
28	3196169	Screw
29	W10655441	Shield, Power Cord
30	W10031780	Screw
31	W10273192	Rod, Door Switch
32	9758701	Spacer, Door
33	W10774446	Bottom, Oven
34	W10627802	Switch, Door
35	W10281322	Kit, Bare Wire Adapter Block
36	W10603482	Rack, Ladder
37	W10563084	Assembly, Convection
38	W10346153	Baffle, Full Convection
39	W10273002	Bracket, Oven Support
40	W10346147	Pan, Bake
41	W10162255	Duct, Cover
42	W10162254	Duct, Cooling
43	W10162259	Assembly, Cooling Fan
44	W10655485	Shield, Wire
45	W10772931	Channel, Rear
46	W10575377	Cover, Wire
47	W10289172	Cover, Back
48	W10686408	Kit, Reservoir (Steam Rack)
49	W10554007	Rack, Steam
50	W10554006	Rack, Maximum Capacity
51	W10554008	Rack, Sliding
52	W10233363	Cord, Power
53	W10558277	Burner Box, Gas Downdraft

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
54	W10162257	Duct, Cooktop
55		The wireless meat probe is a licensed product and covered by the manufacturer total replacement warranty. If the customer has any questions or concerns regarding the accessory please have them call KitchenAid Customer Satisfaction Center toll-free at 1-800-541-6390 or visit our web site at www.KitchenAid.com . No warranty claims will be paid for the wireless meat probe or will this be a service part.
		INSULATION
	W10289173	Insulation, Wrap
	W10575374	Insulation, Bottom
	4820F015-59	Insulation, Strap
	W10162240	Insulation, Back
	7111P017-60	Clamp, Wire
	W10742023	Insulation, Burner Box Gas


MANIFOLD PARTS



MANIFOLD PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10295997	Screw, Valve	6	W10496872	Electrode (Right Rear)	10	W10434277	Orifice (Right Front)
2	W10552120	Orifice, Assembly (Right Front)		W10496870	Electrode (Right Front)		W10657949	Orifice (Right Rear)
	W10552119	Orifice, Assembly (Right Rear)		W10496873	Electrode (Left Rear)		W10657946	Orifice (Left Front)
	W10669616	Orifice, Assembly (Left Rear)		W10496874	Electrode (Left Front)		W10515054	Orifice (Left Rear)
	W10669617	Orifice, Assembly (Left Front)	7	W10669613	Assembly, Manifold	11	W10575401	Clip, Spring Electrode Right Front, Left Front & Left Front
3	W10762686	Bracket, Saddle	8	W10566057	Valve, Gas (Right Rear)		W10256046	Spring, Electrode
4	W10552945	Tube, Supply		W10566062	Valve, Gas (Left Front & Right Front)	12	W10140571	Seal, Switch Shaft
5	W10669619	Harness, Switch Spark		W10566092	Valve, Gas (Left Rear)	13	W10475148	Module, Spark Following Parts Not Illustrated
			9	W10661850	Assembly, Regulator & Bracket		W10681410	Kit, LP Conversion


BLOWER PARTS



BLOWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10661156	Enclosure, Blower	6	W10789431	Kit, Plenum Transition	11	W10661835	Plenum, Side
2	W10572225	Plenum Intake, Gas	7	W10789391	Kit, Blower Installation	12	W10702071	Retainer
3	W10572145	Plenum, Upper	8	W10789388	Kit, Blower	13	W10759311	Gasket, Blower
4	W10575379	Grease, Filter	9	W10788527	Capacitor, Assembly	14	W10642096	Adaptor, Exhaust
5	W10575393	Guard, Filter	10	W10787917	Cover, Capacitor			

DOOR PARTS




DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Handle, Door
	W10551000	Stainless
2	9780274	Screw
3		Badge
	W10518672	Grey
4	W10541882	Liner, Door
5	W10031790	Screw
6	W10541888	Glass, Inner

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10388635	Hinge, Door (Active)
8		Panel, Door
	W10634271	Stainless
9	W10541911	Bracket, Glass Upper
10	W10327235	Handle
11	W10541885	Support, Glass
12	W10031780	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
13	8533988	Screw
14	W10541883	Hinge, Support Rail
15		Scoop, Door
	W10551024	Stainless

DRAWER PARTS



DRAWER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	3196169	Screw
2		Panel, Drawer Front
	W10634248	Stainless

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10318026	Bracket, Mounting
4	8004P024-60	Spacer, Side Panel
5	W10763800	Baffle, Downdraft Drawer Panel

OPTIONAL PARTS (NOT INCLUDED)

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	511873	White Porcelain (2 oz.)

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White (Uncut)

REFINISHING MATERIAL

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	242756	Oven Liner Touch Up Paint

INSULATION

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	261514	Insulation (1-1/2" x 24" x 120")
	240132	Insulation (2-1/2" x 22" x 120")

ACCESSORY PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		CLEANERS / POLISHES
	31605	Kit, Cooktop Care
	31463A	Protectant, Cooktop
	W10355051	Cleaner, Cooktop
	W10355016	Cleaner, Stainless Steel
	WA906B	Scraper, Cooktop
	W10355049	Wipes, Stainless Steel Cleaning
	W10355010	Cleaner, Kitchen & Appliance
	W10275756	Cleaner, Granite
	31617A	Cleaner, Grate & Drip Pan
	W10432019	Alt Cleaning Kit
	W10391473	Pad, Cooktop Cleaning
		MISCELLANEOUS
	4396923	Broiler Pan and Grid
	W10123240	Rack, Broiler Pan & Roasting
	W10432539	Griddle
	W10432545	Kit, Grill
	242905	Kit, Canning Unit
		TRIM KITS
	W10675026	Black
	W10675027	White
	W10675028	Stainless
		BACKSPLASH ASSEMBLY
	W10655449	Black
	W10655448	White
	W10655450	Stainless