



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS

For Model: KECC056RBL04
(Black)

| Illus. No. | Part No. | DESCRIPTION |
|-------------------|-----------------|-----------------------------|
| 1 | | Literature Parts |
| | 8286066 | Installation Instructions |
| | 3192609 | Wiring Diagram |
| | W10162162 | Use & Care Guide |
| | | Safer Cooking Tips |
| | 9762761 | English |
| | W10065852 | French |
| 2 | W10487934 | Cooktop, Glass |
| 3 | 246119 | Screw |
| 4 | W10414006 | Bracket, Switch Mounting |
| 5 | 3183956 | Seal, Switch Cover |
| 6 | 9759094 | Spring Locator |
| 7 | | Switch, Infinite |
| | 3191049 | 1200w/Front Burner |
| | 3191050 | 1800w/Rear Burner |
| 8 | 3192439 | Seal, Limiter |
| 9 | 3193012 | Light, Indicator |
| 10 | | Knob, Control |
| | 9750372FF | Black |
| | 9750372FW | White |
| | 9750372FC | Biscuit |
| 11 | 8286988 | Box, Burner |
| 12 | 4455917 | Bracket, Mounting |
| 13 | 3400093 | Screw |
| 14 | 3196537 | Screw |
| 15 | 8285469 | Seal, Infinite |
| 16 | 7101P309-60 | Screw |
| 17 | 3192721 | Rail, Element |
| 18 | 3192612 | Lamp, Hot Surface Indicator |
| 19 | | Element, Surface |
| | 8523698 | 1200W/Front Burner |
| | 8523696 | 1800W/Rear Burner |

FOLLOWING PARTS NOT ILLUSTRATED

Miscellaneous

4455364 Bracket, Support

OPTIONAL PARTS (NOT INCLUDED)

For Model: KECC056RBL04
(Black)

| Illus. | Part | |
|---------------|-------------|--------------------|
| No. | No. | DESCRIPTION |

**FOLLOWING PARTS
NOT ILLUSTRATED**

WIRING HARNESS PARTS

| | |
|---------|---------------|
| 4457254 | Harness, Main |
| 98997 | Clip, Harness |
| 3400015 | Screw, Ground |
| 4456511 | Conduit |
| 3196160 | Screw |