

K-5871 RIVERBY™ UNDER-MOUNT KITCHEN SINK

Product Information

Applicable prod	Applicable product:				
Under-mount ki	Under-mount kitchen sink				
Fixture*:					
Bowl area	30-1/4" (768 mm) x 17-1/4" (438 mm)				
Water depth	9" (229 mm)				
Drain hole	Ø 3-7/8" (98 mm)				
Faucet holes	Ø 2-3/8" (60 mm)				
* Approximate measurements for comparison only.					

Included components:	
Cut-out template	1166727-7
Under-mount sink kit 23" (584 mm)	1054375

Included accessories:	
Bottom bowl rack, left side	K-6237
Colander with integral cutting board	K-6239
Utility rack with soaking cup	K-6194

Recommended accessories:	mended accessories:		
P-Trap	K-9000		
Optional accessories:			
Under-mount sink kit 36" (914 mm)	K-5807		
Wood cutting board	K-6246		
Bottom bowl rack, right side	K-6255		
Duostrainer _® sink strainer	K-8801		

Installation Notes

Install this product according to the installation guide.

NOTICE: Countertop manufacturer or cutter **must** use the cut-out template provided with the product, or a current one provided by Kohler Co. (call 1-800-4-KOHLER). Kohler Co. is not responsible for cutout errors when the incorrect cut-out template is used.

Fixture conforms to ASME standard A112.19.1/CSA B45.2. All dimensions are nominal.





