LED Exterior Wall Sconce




START FROM HERE

- Make sure power is completely off at the fuse box.
- Have your fixture installed by a qualified licensed electrician
- Prepare everything in a clear area.
- Wear gloves at all times during this installation.
- Read instructions carefully before you start assembly.
- Keep this instruction sheet for future reference.

Technical Support: 1-877-452-6858

Please Note:

- All Kuzco LED fixtures come with pre-wired LED module(s).
- Unless instructed to do so, please do not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage.
- For dimming, an ELV (Electronic Low Voltage) or a triac type of dimmer is required.
- 1. Remove the fixture from its original packaging. Remove the mounting plate (1c) from within the canopy (2a) by unthreading the set screws (2b). Attach the mounting plate (1c) to the electrical junction box (1a) using the screws (1d) provided in the hardware package.
- 2. Attach the canopy to the mounting plate, which is attached to the electrical junction box. First connect all wires correctly G ground to ground, N neutral wire (white to white), L live wire (black to black) with provided marettes (1b) from the hardware package. Align the holes on the canopy (2a) to the mounting plate (1c). Once aligned, Push the canopy (2a) to the mounting plate (1c) and use the set screws (2b) to secure the canopy.
- **3.** To prevent moisture from entering the outlet box and causing a short, seal around the top and side perimeter between the fixture and wall surface with weather resistant caulking. The space at the bottom should be left un-caulked to prevent moisture nuild-up. Apply a small amount of weather resistant caulking aroung the side perimeter between the cap nut and mounting plate
- **4.** You have now completed the installation of your fixture, enjoy.



19054 28th Avenue Surrey, BC Canada V3S 6M3 T: 604 538 7162 TF: 1-855 85 KUZCO F: 604 538 7196 W: kuzcolighting.com 20160527