

Tessa Wall

WS757_ 1.0



GENERAL PRODUCT INFORMATION:

This product is suitable for damp locations.




This product can mount either to a 4" square electrical box with a round plaster ring or an octagon electrical box.

This product can be dimmed with a standard incandescent dimmer.

CAUTION - RISK OF FIRE
 This product requires installation by a qualified electrician. Before installing be sure to read all instructions and **TURN THE POWER TO THE ELECTRICAL BOX OFF.**




Install the Mounting Plate




1 With the Allen wrench provided, remove the two fixture screws.

2 Remove the mounting plate from the back of the fixture.




3 Install the mounting plate onto the electrical box with the two #8-32 screws provided.

Install the Fixture




- 1 Connect the mounting plate ground wire to a suitable ground in accordance with local electrical codes.
- 2 Connect the white fixture wire to the neutral power line wire with a wire nut.
- 3 Connect the black fixture wire to the hot power line wire with a wire nut.



- 4 Remount the fixture onto the mounting plate and secure it tightly with the two fixture screws using the allen wrench.

Install the Lamp



CAUTION: To reduce the risk of a burn or electric shock during lamping and re-lamping, disconnect the power to the fixture.

Use **MAX 60 Watt** S-21 Squirrel Cage medium base lamp or other style **60 Watt** medium base lamp.



- 1 Screw the lamp into the socket.

SAVE THESE INSTRUCTIONS!

LBL

7400 Linder Ave, Skokie, IL 60077
800.323.3226 - 847.626.6300

www.lblighting.com

© 2013 LBL Lighting. All rights reserved. The "LBL Lighting" graphic is a registered trademark of LBL Lighting. LBL Lighting reserves the right to change specifications for product improvements without notification.

A Generation Brands Company