

Job Name/Location:

Tag #:

Date:

For: ☐ File ☐ Resubmit

PO No.:

☐ Approval ☐ Other _____

Architect:

GC:

Engr:

Mech:

Rep:

(Company)

(Project Manager)

**ARVU063ZEA2**

Energy Recovery Ventilator (ERV)

**Performance:**

Nominal Capacity (CFM)	590
Power Input SH (W)	470

Capacities are in accordance with AHRI Standard 1060.

Heat Exchanger Data:

Air-to-Air Heat Exchanger	Cross flow fixed core
Quantity	1
Temperature Exchange Efficiency (%)	
Cooling (fan speed SH)	59
Heating (fan speed SH)	58
Enthalpy Exchange Efficiency (%)	
Cooling (fan speed SH)	34
Heating (fan speed SH)	49

Electrical:

Power Supply (V/Hz/Ø)	208-230/60/1
Rated Amps SH (A)	3.44

Controls Features:**Stand Alone Mode:**

- Can be operated independently

Ventilation Heat Exchange Mode:

- Draws outdoor air and indoor exhaust air across air-to-air heat exchanger

Ventilation Normal (Bypass) Mode:

- Controls by-pass damper to bypass air-to-air heat exchanger and draw in untempered outdoor air

Optional Accessories:

- ☐ LG Programmable Thermostat - PREMTA000
- ☐ PI485 (required for central controller) - PSNFP14A0

Operating Range:

Outdoor Temperature (°F DB)	14-113
-----------------------------	--------

Unit Data:

Sound Pressure SH/H/L dB(A)	41/39/33
Filter	Washable
Quantity	2
Net Unit Weight (lbs)	148
Shipping Weight (lbs)	177

Fan:

Type	Cross Flow
Quantity	2
Motor/Drive	Brushless Digitally Controlled/Direct
Airflow Rate SH/H/L (CFM)	589/589/471
External Static Pressure SH/H/L (in wg)	0.64/0.36/0.20

Notes:

- 1.SH = super high speed, H = high speed, L = low speed
- 2.All communication cable to be minimum 18 AWG, 2-conductor, stranded, shielded and must comply with applicable local and national code.
- 3.Power wiring cable size must comply with the applicable local and national code.
- 4.Must follow installation instructions in the applicable LG installation manual.



ARVU063ZEA2
Energy Recovery Ventilator (ERV)



Tag #: _____
Date: _____
PO No.: _____

