## **ITEM NO.: LS-19856**

## **ASSEMBLY INSTRUCTIONS:**

## VERY IMPORTANT

PLEASE READ THOROUGHLY. MAKE SURE YOU PROPERLY ALIGN POLES BEFORE SCREWING THEM TOGETHER TO AVOID DAMAGING CONNECTION THREADS. NOT ADHERING TO THIS PROCEDURE MAY VOID YOUR WARRANTY.

WARNING: MAKE SURE POWER SUPPLY IS TURNED OFF AT MAIN BREAKER PRIOR TO INSTALLATION. PLEASE READ THOROUGHLY. CAREFULLY UNPACK THIS LAMP AND PLACE ON A SOFT FLAT SURFACE.

- 1. There are 4pcs of poles (B, C, D) with different length (16"Lx2pcs + 10"L x1pc + 6"L x1pc). Before you install the lamp, please choose the pole length to determine height for your lamp. Then feed the cord through the poles (B, C, D), canopy. All poles (B, C, D) may not be used based on ceiling height.
- 2. Connect the poles (B, C, D) together and screw the another side of pole onto the fixture body (A).
- 3. Fasten the crossbar (O) to the ceiling outlet box with Outlet box screw (P).
- 4.Connect the NEUTRAL wire silver(K) from fixture to black wire (K) (NEUTRAL) from driver output using wire connector(M).


  Connect the LIVE wire silver(S) marked words from fixture to the RED wire(S)(LIVE) from driver output using wire connector(M).
- 5.Connect the NEUTRAL wire (N, white) from driver input to the NEUTRAL wire (N) from power supply using wire connector(M).

  Connect the LIVE wire (L, black) from driver input to the LIVE wire(L) from power supply using wire connector(M).
- 6.Connect the GROUND wire (H) from canopy of fixture to the ground wire (G) from ceiling outlet box, using the wire connector (M) (Or attach them to the crossbar (O) with the green Ground screw (I)).

NOTE: Never connect the ground wire to live or neutral power supply wire. If outlet box does not have ground wire, please connect the ground wire from fixture to crossbar.

- 7. Attach the canopy (E) to the crossbar (O) and secure with finial (R).
- 8. Install bulbs into the sockets.
- 9.Relamping: Make sure turn off the fixture before replacing bulbs. Insert bulbs to the socket of fixture.

Use 9 PCS 3W (Maximum) G4 LED BULB. (LED BULB included)



LITE SOURCE INC.

(L) SUPPLY

WIRE (LIVE

(II) DRIVER

(L) DRIVER INPUT WIRE (LIVE) (N) SUPPLY WIRE (NEUTRAL)

(N) DRIVER INPUT WIRE (NEUTRAL)

(H) FIXTURE GROUND WIRE

(Q) 8-32x2<sup>1</sup>"SCREW (2PCS)

-(S) FIXTURE WIRE (LIVE)

(K) driver output wire(neutral)
(K) FIXTURE WIRE(NEUTRAL)

(S) DRIVER OUTPUT WIRE(LIVE)
(M) WIRE CONNECTORS(5PCS)

(O) CROSSBAR

(E) CANOPY

-(R) FINIAL (2PCS)

(D) POLE 1/2"x16" (2PCS)

(C) POLE 1/2"x10" (1PC)

(I)GROUND SCREW

(P) 8-32x<sub>2</sub><sup>1</sup>"OUTLET BOX SCREW (2PCS)

- **\*\* PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.**
- **\*\* SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.**