ITEM NO LS-3495

ASSEMBLY INSTRUCTIONS

- 1. This portable mirror has a plarized plug (one blade is wider than the other) as a safety feature, to reduce the resk of electric shock. This plug will fit in a polarized outlet only one way. If it still does not fit. contact a qualified electrician. Never use with an extension cord unless plug can be fully insert. DO not attempt to defeat this safety feature. (Fig. 1)
- 2. In the event that a bulb needed to be replaced.
 - (A) Unplug unit from wall outlet, and wait at least 5 minutes until bulb cool down.
 - (B) Unscrew both mirror case screws on each side of mirror case. (Fig.2)
 - (C) Relamp with new bulb. (no more than 25watts) (Fig. 3)
 - (D) Screw back mirror case screws.
- 3. You may easily adjust mirror position by moving the Swing Arm or tilt the mirror angle by adjusting the mirror case (Fig.4)
- 4. Use soft dry cloth to clean the mirror or the unit. Do not use abrassive chemicals for cleaning.

"IMPORTANT SAFETY INSTRUCTIONS"

This portable lamp has a polariaed plug (one blade is wider than the other). As a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

Use 25 watt1pcs (maximum) C type bulb (bulbs included)

- X PLEASE INFORM YOUR DEALER IMMEDIATELY IN CASE OF ANY PARTS SHORTAGE.
- X SAVE THIS INSTRUCTION FOR FUTURE REFERENCES.



