



Instruction Sheet

Subject: K00470 K00472 K00473 Bin Adapter

BIN ADAPTER

K00470 - 30" ICE MACHINE ON 48" BIN K00472 - 22" ICE MACHINE ON A 30" BIN K00473 - 22" ICE MACHINE ON A 48" BIN

A Warning

Authorized Service Representatives are obligated to follow industry standard safety procedures, including, but not limited to, local/national regulations for disconnection / lock out / tag out procedures for all utilities including electric, gas, water and steam.

These instructions are used for installing the following:

- 22" ice machines on 30" B, K or D model bins
- 22" ice machines on 48" B, K or D model bins
- 30" ice machines on 48" B, K or D model bins
- 1. Remove protective coating from support rail and bin adapter prior to assembly.
- 2. Refer to drawing and place support in position. Angled flange of support must face the front of the bin. Apply foam tape on top of the support.

- 3. Place bin adapter on bin No fasteners are required.
- 4. Apply foam tape from the kit around bin top opening.
 - Foam tape applied to the front of the bin opening must be located under the ice machine bottom rail.
 - B. Apply foam tape around the sides and rear of the bin top opening.
- Place bin in final position and adjust legs to level bin in all directions.
- 6. Refer to Ice Machine Installation Manual for ice machine installation. Clean and sanitize the ice machine and bin when installation is complete.



