

909106

INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

CAUTION

WARNING: Risk of Fire. Consult a qualified electrician to ensure correct branch circuit conductor.

Turn off the main power at the circuit breaker before installing the fixture in order to prevent possible shock.

GENERAL

All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the fixture and the mounting package from the box and make sure that no parts are missing by referencing the illustration.

ASSEMBLY AND INSTALLATION

1. Lock the column stem (14) with loop (13) on the nipple of the fixture(15).
2. Determine the length of chain(12) required to hang the fixture at the desired height. Open the quick link (11) and attach quick links (11) to the loop of canopy (9) and the appropriate length of chain (12). Close quick link (11).
3. Open the quick link (11) at the other end and then hook onto loop(13) of the column stem (14),close the quick link(11).Pass wires carefully through chain (12) and loop of canopy(9).
4. Loosen mounting screw(10) to remove mounting plate (6) from canopy(9).
5. Attach the mounting plate (6) with box screw (8) to the outlet box (1).
6. Pull out the outlet wires and ground wire from the outlet box(1). Make wire connections with wire nut (5).
 - Ribbed wire (w/o marking) or white wire from light to White wire (3) from power source.
 - Smooth wire (w marking) or black wire from light to Black wire (2) from power source.
 - Tie the ground wire from fixture and from outlet box(1) to the ground screw(7) on the mounting plate(6).
7. Attach the fixture canopy(9) to the outlet box (1), secure it with mounting screw (10).
8. Remove the socket ring (18) from the socket (16). Place the glass shade (17) over the socket then secure with socket ring (18) .
9. Install bulbs: (bulbs not include).
(Don't exceed the maximum capacity recommended on the socket rings).

INSTALLATION IS NOW COMPLETED

