## INSTALLATION INSTRUCTIONS

Item#5071/5072/5073/5074/5075/5076-84/66A/44-L

### **READ AND SAVE THESE INSTRUCTIONS**

# **W**arning!shutpoweroffat fuseorcircuitbreaker.

## AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

#### **READ AND SAVE THESE INSTRUCTIONS**

### **PREPARATION**

- 1. Shut off power at the fuse box or circuit breaker box and remove the old fixture including the mounting hardware.
- 2. Carefully unpack your new fixture and lay out all the parts in a clean area. Take care not to misplace any small parts necessary for installation.

## **INSTALLATION & ASSEMBLY (Fig.1 & Fig.2)**

- 3. An octagonal junction box must be installed at each desired location, before installing the luminaire. The box must have a depth of at least  $\frac{1}{2}$ ".
- 4. Twist counterclockwise to loosen canopy screws (Fig. 1).
- 5. Remove mounting bracket from luminaire. Do not remove any other parts (Fig. 1).
- 6. Adjust mounting bracket so the arms are facing away from junction box. Pull power supply wires from junction box through the center opening of mounting bracket (Fig. 2).
- 7. Attach mounting bracket to junction box, make sure mounting bracket is flushed and leveled before tightening with mounting screws (Fig. 2).
- 8. Make electrical wiring connections between luminaire and power supply (see ELECTRICAL WIRING below).
- 9. Position luminaire over junction box, pass canopy over arms from mounting bracket.
- 10. Secure canopy and mounting bracket with canopy screws.
- 11. Select desired LED color temperature by using the switch of luminaire situated on canopy.

## **ELECTRICAL WIRING (Fig. 3)**

- 12. Strip 3/8" of bare power supply wires from junction box.
- 13. Follow the wires connection guide to connect wires from luminaire to power supply wires from junction box, using the wire nuts.
- 14. Connect neutral wire (white) from junction box to neutral wire (white) from luminaire.
- 15. Connect hot wire (black) from junction box to live wires (black) from luminaire.
- 16. Connect green ground wire from luminaire to bare copper ground wire from junction box, using a wire nut.
- 17. Once the connections are done, push wires back inside junction box.

Your installation is now complete. Return power and test the fixture.

IMPORTANT: FIXTURE SHOULD BE INSTALLED BY A QUALIFIED ELECTRICIAN TO ENSURE PROPER WIRING AND INSTALLATION.

#### Care and maintenance

Use a clean, soft cloth to wipe the surface of the fixture.

DO NOT use any cleaners with chemicals, solvents or harsh abrasives.

**Dimming:** Dimmable with ELV and/or LED compatible wall dimmer switches.









