INSTALLATION INSTRUCTIONS FOR 4181-282 4182-282

For Wall Mount Fixture

©Minka Lighting, Inc.

This product is protected by United States Federal and/or

State Law, including Patent and/or Copyright laws.

WARNING! SHUT POWER OFF AT FUSE OR CIRCUIT BREAKER. AVERTISSEMENT! COUPER LE COURANT AU NIVEAU DES FUSIBLES OU DU DISJONCTEUR.

MOUNTING THE FIXTURE

INSTALLATION(Fig.1)

- Shut off the power at the circuit breaker and remove the old fixture from ceiling, including the old crossbar.
- Carefully unpack the new fixture and lay all the parts on a clear surface.
- Attach the crossbar to the junction box using two junction box screws (Size: #8-32*1*L). The side of the crossbar marked "GND" must face out.
- Thread the nipple part way into the center hole of the crossbar and secure with hex nut.
- 5. Follow wiring instructions carefully (see fig.2)
- Place the fixture body (C) over the nipple, then tighten it with the cap nut (B).
- Place the tube (A) over the socket of the fixture body (C).
- 8. Install the light bulbs (not included) in accordance with the fixture's specifications: DO NOT EXCEED THE MAXIMUM WATTAGE RATING! (NE PAS DEPASSER LA PUISSANCE NOMINALE MAXIMALE!)

WIRING (Fig.2)

- Connect the electrical wires as follows. Connect the black wire from the fixture to the black house (hot) wire. Connect the white wire from the fixture to the white (neutral) house wire. Make sure all wire nuts are secured. You may wrap the connections with electrical tape. If your outlet box has a ground wire (green or bare copper) connect fixture's ground wire to it. Otherwise attach the bare copper fixture wire to the green ground screw (Size: #8-32*3/8*L) on the crossbar.
- Tuck the wire connections neatly into the wall junction box.







