


Note: Please check your print settings and make sure it is set to “Actual size”.

Hint: To save ink, change print settings to “grayscale” and change the print quality to “fast draft”.

Fixture dimensions: 7.5”W x 14”H x 8.5”E



A



B





C

D

