


Replacement Parts

Keep this manual for ordering replacement parts.



- 1 Screws
- 2 Locking nut
- 3 Metal gasket
- 4 Rubber gasket
- 5 Extension pipe
- 6 Bottom gasket
- 7 Faucet base
- 8 Set screw
- 9 Plastic locking ring
- 10 O-rings
- 11 Plastic locking ring
- 12 O-ring
- 13 Spout
- 14 Gasket
- 15 Aerator
- 16 Aerator holder
- 17 Handle lever
- 18 Screw
- 19 Handle
- 20 Cartridge cover
- 21 Locking nut
- 22 Cartridge
- 23 Hot & cold waterlines