









- Please check your product packaging to make sure the included accessories are in the list of standard accessories. If any parts are missing please contact your dealer immediately.
- Do not allow any sharp objects to come into contact with the cabinet, as it will scratch the surface.
- Continuous and prolonged exposure to direct sunlight may cause discoloration to the wood.
- Do not put any hot appliances directly on or near the cabinet.
- Please avoid using cleaning products that contain bleach or ammonia.
- Wood surfaces should only be cleaned with wood care products such as soapy water or furniture polish.



INSTALLATION




MAIN BODY PARTS




INSTALLATION PARTS

INSTALLATION TOOLS



INSTALLATION, REMOVAL, ADJUSTMENT OF TOP FAST-LOADING HINGE



install


remove

adjust the height

adjust the lateral

adjust the deep

DRAWER ADJUSTMENT



install

remove

INSTALLATION INSTRUCTIONS

