


Barn Door Hardware Installation

For Use with 60" Bearing Strap Hanger Kits

Parts Included:








DH = Door Height

Recommend that you layout your door and hardware on the floor first to determine spacing.


Measure twice Mount once

Rail must be level to keep door from moving by itself!


1



All Rail Mounts must be screwed into a solid Wood Header




Hanger position from the edge can vary based on your door design. Position Shown is for a flat Surface Door you may have to Adjust to center Hanger onto the vertical styles of your door



Anti Jump Disks keep your door from accidently coming off the Rail. They are installed offset with the Screw outside the rail in case you need to remove the door later.

Once your installation is complete rotate the Disks under the rail and tighten down.




The Guide Stabilizes the door by keeping the bottom from Swinging. Kit includes both a Mortise (Grove in the bottom of the door) and a Non-Mortise option.


This step will require hanging and removing the door to measure and install the Guides

Hang the door and slide it into the Floor Guide then Rotate the Anti Jump Disks under the rail and tighten down the screws to lock them in place

Door Stop Positioning Instructions 8



Adjust your Door Stops to your desired position and lock down your Door Stops with the Allen Wrench Provided




Door should Slide smoothly in both Directions

Optional Accessories

Soft Close Adapter Kit

Each kit Contains a left and right Soft Closer that mounts behind the Rail and keeps children from slamming doors.





Expansion Parts

24" Rail Extensions, By-Bass brackets, Rail Joiners, Masonry Rail Mounts

