

Illuma Flex Buying Guide

Step 1: Choose your fixture(s)

Heads



P6104

P6115

P6116



P6112

P6105

Pendants



P9205

P9206

P9207



P9200

P9201

P9202



P6328

P6329

P6369



P9219

Step 2: Select your mounting type

Ceiling Surface Mount



P6227 / P6228

P9123

Ceiling Mount - Remote Power



P6227 / P6228

P8782, 83, 84, 85

P8786



P8752, 53, 54, 55

P8790, 91, 92, 93

Wall Mount



P6227 / P6228


P8706



P8752, 53, 54, 55

P8752, 53, 54, 55

Monopoint



P8780

P8794