
Installation Guide For Styles BLG2818BN and BLG2818OZ






Fixture Height Adjustable 24" to 74.5"

⚠ Warnings and Cautions

Turn off the electricity at the circuit breaker before installation. Consult a licensed electrician if in doubt about installation.


Turn off power to the fixture and allow the bulbs to cool before replacing.




Ceiling Canopy

Bulbs

Shade & Cap












Step 1 Adjust fixture chain length




Step 2 - 3 Install Fixture Chain











STEP 4



Feed the fixture wires through the loop






Supply wire from fixture ribbed side or identified with the Label "N"


> supply wire from fixture smooth side or identified with the label "L"

Ground wire from Fixture







STEP 6



STEP 7



STEP 8



©2019 QuoizelInc.

visit us on-line at www.quoizel.com

Released Date: 2019-07-19