

SAFETY INFORMATION

Please read and understand this entire manual before attempting to assemble, install or operate the product.


WARNING

- RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE - Use bulbs specified by the markings and/or labels on the fixture.

CAUTION

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED




CARE AND MAINTENANCE


- Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.

If you need further assistance call Quozel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at www.quezel.com.

PACKAGE CONTENTS



MOUNTING HARDWARE




INSTALLATION

1 Install Rods

Optional Rods:


- 8 Feet Ceiling:
(2) 12"L Rods.
- 9 Feet Ceiling:
(1) 6"L Rods + (2) 12"L Rods.
- 10 Feet Ceiling:
(2) 6"L Rods + (2) 12"L Rods.



2 Install Fixture Loop



3 Install Crossbar Assembly




4 Install Fixture Chain




OPTIONAL: Adjust Chain as desired, using pliers and soft cloth (neither included).

Suggested chain length for Ceiling height:
 8 feet ceiling: use 7 links of chain and 2 quick links
 9 feet ceiling: use 17 links of chain and 2 quick links
 10 feet ceiling: use 27 links of chain and 2 quick links.




5 Pull Supply Wires

Pull the supply wires with ground wire through the chain alternate links.




6 Wiring



INSTALLATION

7 Install Ceiling Canopy




8 Install Shades and Bulbs

Install five correct bulbs referring to fixture markings and/or labels for maximum wattage.

**Recommended Bulb Type
(not included):**




BULB BASE TYPE
Candelabra (E12)



BULB SHAPE
TYPE B

* Remove Candle covers on the Sockets, replace them with Optional Candle Covers if you want.



Your installation is now complete! Restore electricity and save this sheet for future reference.