

REGINA ANDREW

DETROIT

ITEM NO: 14-1017 Raven Floor Lamp

PLEASE NOTE THAT IF ADJUSTABLE CLUTCH IS NOT LOOSENED BEFORE ADJUSTING THE HEIGHT, PERMANENT DAMAGE TO THE MECHANISM MAY OCCUR.

ASSEMBLY INSTRUCTIONS

1. Carefully remove all parts from box and remove all plastic covering from lamp parts.
2. Attach Pipe to Base by rotating the Pipe clockwise. Pull out the cord from the Base.
3. Adjust the height of the lamp by rotating the adjustable clutch counterclockwise to loosen, then tightening.
4. The shade can be moved up and down by loosening the swivel knob and tightening it.
5. Insert the proper bulb into the socket. **NOTED: LED BULBS ARE RECOMMENDED.**
6. Insert the polarized plug into wall outlet, turn on switch and enjoy your new lamp.

CLEANING AND CARE:

Use a soft cloth only, do not use any chemical or abrasive cleaners.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one-way. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

Made in China

