
FIND YOUR SHAPE

FIND YOUR DIAMETER




Cabinet door is hinged and does not attach to lazy susan





Cabinet door is inset and must attach to lazy susan*


* If you are replacing an existing lazy susan, the existing susan will be attached to the door











(1) FIND YOUR SHAPE (2) FIND YOUR DIAMETER*

(3) COMPARE MEASUREMENTS TO THE AVAILABLE PRODUCT SIZES/DIMENSIONS TO VERIFY FIT

*Measure 100 & 102. Subtract 2" from the smaller of the two measurements to determine the largest diameter of Lazy Susan that can fit into the cabinet. (Example: If 1010 is 32" and 1020 is 30", max diameter is 28").

NOTE: This product can be added to new or existing cabinetry or can replace an older model.

WILLIT FIT?