


PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS

DESCRIPTION/LA DESCRIPCION/DESCRIPCIÓN :Four Door Console/Console quatre portes/
Consola de cuatro puertas



A *

x4 Adjustable Shelf
x4 Tablette ajustable
x4 Estante ajustable




B *

x6 Adjustable leveler-Brown
x6 Patin réglable
x6 Nivelador ajustable



C *

x1 Tipping restraint
x1 Liste des pièces de
quincaillerie antibasculément
x1 Abrazadera antivuelco




D *

x16 Shelf Supports
x16 Supports Pour Tablette
x16 Soporte De Las Repisas



E *

x6 Legs
x6 jambes
x6 Piernas






* Replaceable Part

ASSEMBLY INSTRUCTIONS/ NOTICE DE MONTAGE/ INSTRUCCIONES DE MONTAJE




DESCRIPTION/LA DESCRIPCION/DESCRIPCION : Four Door Console/Console quatre portes/
Consola de cuatro puertas

⚠ WARNING	
	<p>Children have died from furniture tipover. To reduce the risk of furniture tipover:</p>
	<ul style="list-style-type: none"> • ALWAYS install tipover restraint provided.
	<ul style="list-style-type: none"> • For use with televisions weighing 170 lbs (77.11 kgs) or less. Use with heavier televisions may result in instability causing tip-over resulting in death or serious injury.
	<ul style="list-style-type: none"> • NEVER allow children to stand, climb or hang on drawers, doors, or shelves. • NEVER open more than one drawer at a time. • Place heaviest items in the lowest drawers.
	<p style="text-align: center;"><i>This is a permanent label. Do not remove!</i></p>




* Replaceable Part

REPLACEABLE PART/ PARTIE REMPLACABLE/ PARTE REEMPLAZABLE



DESCRIPTION/LA DESCRIPCION/DESCRIPCIÓN : Four Door Console/Console quatre portes/
Consola de cuatro puertas




- A** *
RP301671-SHELF
x4 Adjustable Shelf
x4 Tablette ajustable
x4 Estante ajustable




- B** *
RC-FG-BROWN
x6 Adjustable leveler-Brown
x6 Patin réglable
x6 Nivelador ajustable




- C** *
RC-ANTI-TIP
x1 Tipping restraint
x1 Liste des pièces de quincaillerie antibasculement
x1 Abrazadera antivuelco



- D** * RP301671-SUPP
x16 Shelf Supports
x16 Supports Pour Tablette
x16 Soporte De Las Repisas





- RP301671-CHINGE
* x6 Center Door Hinge
x6 Charnière de porte
x6 Bisagra de la puerta



- * RP301671-CATCH
* x4 Door Catch
Catch de aimant
Captura de imá



- * RP301671-GRO
x2 Grommet
x2 Oeillet
x2 Ojal



- RP301671-SHINGE
* x6 Side Door Hinge
x6 Charnière de porte
x6 Bisagra de la puerta



- E** *
RP301671-LEG
x6 Legs
x6 jambes
x6 Piernas

* Replaceable Part