


PARTS LIST / LISTE DES PIÈCES / LISTA DE PIEZAS

DESCRIPTION/LA DESCRIPCION/DESCRIPCIÓN :Entertainment Credenza/
Bahut de divertissement murale/Aparador de entretenimiento



A *

x4 Adjustable Shelf
x4 Tablette ajustable
x4 Estante ajustable





B *

x5 Adjustable leveler-White
x5 Patin réglable
x5 Nivelador ajustable



C *

x1 Tipping restraint
x1 Liste des pièces de quincaillerie antibasculement
x1 Abrazadera antivuelco




D *

x16 Shelf Supports
x16 Supports Pour Tablette
x16 Soporte De Las Repisas

* Replaceable Part

ASSEMBLY INSTRUCTIONS/ NOTICE DE MONTAGE/ INSTRUCCIONES DE MONTAJE





DESCRIPTION/LA DESCRIPCION/DESCRIPCIÓN :Entertainment Credenza/
Bahut de divertissement murale/Aparador de entretenimiento

WARNING

Children have died from furniture tipover.
To reduce the risk of furniture tipover:

- ALWAYS install tipover restraint provided.
- For use with televisions weighing 170 lbs (77.11 kgs) or less. Use with heavier televisions may result in instability causing tip-over resulting in death or serious injury.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

This is a permanent label. Do not remove!










* Replaceable Part

REPLACEABLE PART/ PARTIE REMPLACABLE/ PARTE REEMPLAZABLE



DESCRIPTION/LA DESCRIPCION/DESCRIPCIÓN :Entertainment Credenza/
Bahut de divertissement murale/Aparador de entretenimiento



* Replaceable Part