





ASSEMBLY INSTRUCTIONS

ITEM NO.: 6-7403-3-39



FOR MOUNTING DIRECTLY TO THE CEILING:

1. Carefully unpack and identify all parts referring to the illustration for parts identification.
2. Turn power to the installation point **OFF**.
3. Attach the both ends of decorative chain (C) to the hooks on the fixture body (A) and ring (D) as shown.
4. Place the candle sleeve (E), (F) and (G) onto each socket of fixture body (A).
5. Attach the both ends of beads string (H), (I) to the hole on the fixture body (A) and ring (D) as shown.
6. Install proper bulbs (not provided) to sockets referring to the markings and/or labels on the fixture for maximum wattage.
7. Restore power to the installation point **ON**. Retain this sheet for future reference.



FOR CHAIN HUNG ASSEMBLY:

8. Carefully unpack and identify all parts referring to the illustration for parts identification.
9. Turn power to the installation point **OFF**.
10. Thread the loop (B) onto the top center nipple of fixture body (A), hands tighten until snug.
11. Attach the both ends of decorative chain (C) to the hooks on the fixture body (A) and ring (D) as shown.
12. Place the candle sleeve (E), (F) and (G) onto each socket of fixture body (A).
13. Attach the both ends of beads string (H), (I) to the hole on the fixture body (A) and ring (D) as shown.
14. Install proper bulbs (not provided) to sockets referring to the markings and/or labels on the fixture for maximum wattage.
15. Restore power to the installation point **ON**. Retain this sheet for future reference.