


Indicator Guide



Charging Guide

Charging indicator while plugged in

- Solid Green: Fully charged
- Flashing Yellow: 30 - 60% battery
- Flashing Green: 60 - 100% battery
- Flashing Red: 0 - 30% battery

Car Mode Indicator

- Solid Blue: Car Mode
- Flashing Blue: Car Standby Mode

Safety

- Do not use a quick charger.
- Do not leave diffuser in direct sun or a hot humid place.
- Do not invert, tilt, or rotate diffuser.
- If diffuser is tipped over, P1 & 2H indicators will flash and diffusion will stop. If the diffuser remains tipped for 10 minutes it will automatically shut down.
- The interval between charging should not exceed 3 months. Charge regularly to maintain battery lifespan.



Questions or Comments?

SCENTBRIDGE.COM
SERVICE@SCENTBRIDGE.COM
(833) 723 6835 - opt 1




HOME & CAR FRAGRANCE DIFFUSER



USER MANUAL

Indicator Guide



Charging Guide

Charging indicator while plugged in

- Solid Green: Fully charged
- Flashing Yellow: 30 - 60% battery
- Flashing Green: 60 - 100% battery
- Flashing Red: 0 - 30% battery

Car Mode Indicator

- Solid Blue: Car Mode
- Flashing Blue: Car Standby Mode

Safety

- Do not use a quick charger.
- Do not leave diffuser in direct sun or a hot humid place.
- Do not invert, tilt, or rotate diffuser.
- If diffuser is tipped over, P1 & 2H indicators will flash and diffusion will stop. If the diffuser remains tipped for 10 minutes it will automatically shut down.
- The interval between charging should not exceed 3 months. Charge regularly to maintain battery lifespan.



Questions or Comments?

SCENTBRIDGE.COM
SERVICE@SCENTBRIDGE.COM
(833) 723 6835 - opt 1



HOME & CAR FRAGRANCE DIFFUSER



USER MANUAL

Getting Started

- Unscrew the atomizer head by turning it counterclockwise and lifting up to remove it.
- Insert the straw into a 10 mL ScentBridge fragrance bottle and tighten securely.
- Reinsert the atomizer head with the attached fragrance bottle into the diffuser and tighten.
- Press the atomizer head down and twist an additional quarter turn to lock it into place.



Diffuser Modes

HOME MODE: ScentSolo will diffuse fragrance at the selected intensity level for the set duration.

CAR MODE: ScentSolo will diffuse fragrance at the selected intensity level only when movement or vibration is detected. (No time indicator will be illuminated.) After 15 minutes without movement, the device will enter Sleep Mode and will automatically reactivate when movement is detected.

The diffuser will remain in Car Mode indefinitely unless the battery is depleted or the settings are changed.

CHARGING MODE: The indicator light will flash red when the battery is low. When plugged in, the light will flash—refer to the color chart for details.



Operating Instructions

POWER ON/OFF: Press and hold top button [⏻] for 2 seconds. Active grade level will light up (P1, P2, P3).

CHANGING GRADE LEVEL: Short-press the top button to cycle through Grade Levels (P1, P2, P3)

CAR MODE: Press and hold the bottom button [🚗] to activate. Car Mode Indicator Light will turn solid blue. Sleep Mode will activate if no movement/vibration is detected within 15 minutes.

Grade/Intensity	Work Time (S)	Pause Time (S)	Approx. Oil Consumption (ml/h)
P1	5	300	0.01
P2	10	100	0.06
P3	10	30	0.16

Getting Started

- Unscrew the atomizer head by turning it counterclockwise and lifting up to remove it.
- Insert the straw into a 10 mL ScentBridge fragrance bottle and tighten securely.
- Reinsert the atomizer head with the attached fragrance bottle into the diffuser and tighten.
- Press the atomizer head down and twist an additional quarter turn to lock it into place.



Diffuser Modes

HOME MODE: ScentSolo will diffuse fragrance at the selected intensity level for the set duration.

CAR MODE: ScentSolo will diffuse fragrance at the selected intensity level only when movement or vibration is detected. (No time indicator will be illuminated.) After 15 minutes without movement, the device will enter Sleep Mode and will automatically reactivate when movement is detected.

The diffuser will remain in Car Mode indefinitely unless the battery is depleted or the settings are changed.

CHARGING MODE: The indicator light will flash red when the battery is low. When plugged in, the light will flash—refer to the color chart for details.



Operating Instructions

POWER ON/OFF: Press and hold top button [⏻] for 2 seconds. Active grade level will light up (P1, P2, P3).

CHANGING GRADE LEVEL: Short-press the top button to cycle through Grade Levels (P1, P2, P3)

CAR MODE: Press and hold the bottom button [🚗] to activate. Car Mode Indicator Light will turn solid blue. Sleep Mode will activate if no movement/vibration is detected within 15 minutes.

Grade/Intensity	Work Time (S)	Pause Time (S)	Approx. Oil Consumption (ml/h)
P1	5	300	0.01
P2	10	100	0.06
P3	10	30	0.16