



SHAWS® SHAKER KITCHEN COLLECTION



Shown with: Perrin & Rowe® Holborn™ Pull-Down Kitchen Faucet with U-Spout, Holborn™ Filter Kitchen Faucet

The Shaker™ apron front fireclay sink is a modern interpretation of the 1897 original. Named for the design movement that believed less is more, this Shaker farmhouse sink takes a minimalist approach. Instead of the iconic apron front with rounded corners, the Shaker has a clean, rectangular shape with squared-off sides and thinner walls for a slimmer, more minimal look. Durable and lustrous, its classic farmhouse roots and authenticity are always apparent. And like all Shaws sinks, the Shaker is made by hand to last a lifetime.

AVAILABLE FINISHES



WH
White



PCT
Parchment



MG
Matte Grey



MB
Matte Black

Lead times may vary



SHAWS® SHAKER KITCHEN COLLECTION

BAR/FOOD PREP



RC1818

MAIN KITCHEN SINKS



MS2418



MS3018



MS3318



MS3320



MS3518



MS3618



MS3918



UM2318



UM3018