WALL-MOUNT MAILBOX

BEFORE INSTALLING

Read entire mailbox installation instructions. Observe all local building and safety codes. For the following installation instructions it is assumed that any old fixtures have been removed and any repairs to the wall have been completed.


INSTRUCTIONS

Unpack and inspect the product for any shipping damages. If you find damages, do not install. Contact Customer Service at 1.866.855.2284. If you need assistance or have questions while installing your mailbox contact Customer Service.

We recommend consulting a professional if you are unfamiliar with installing hardware fixtures. Signature Hardware accepts no liability for any damage to the mailbox or wall, for personal injury during installation.

Wall-mount mailboxes should be located in a location that is protected from snow, rain, and strong winds. If possible, choose a location that is protected by a wall, alcove, overhang, or other architectural feature of your home.

TOOLS AND MATERIALS:



INSTALLATION

1. Hold the mailbox in place in the mounting location and mark the locations of the mounting holes. Use a level to ensure that the mounting holes are aligned properly.

2. Install the mounting hardware. Use hardware that is suitable for the wall material. This can be purchased at your local hardware store if not included with your mailbox.

3. Hang the mailbox on the mounting hardware. Tighten mounting screws from inside the mailbox until the mailbox is secure.

) SIGNATURE HARDWARE

customer service: 1.866.855.2284 signature**hardware**.com