



3801-T48 48" Square Dining Table Assembly Instructions








IMPORTANT : PLEASE READ COMPLETE INSTRUCTION SHEET PRIOR TO ASSEMBLY!
 Identify all parts packed in carton against the parts list. Remove all protective materials, place parts on a nonabrasive surface to avoid scratching. If any parts are missing or damaged, DO NOT attempt to assemble.

Step 1: Place table top upside down on a flat, soft surface.

Attach legs with supplied bolts and lock washers and metal washers.

Step 2: Tighten all bolts. Cover all bolts with plastic bolt caps.

Turn the table in the upright position. Your table is now ready for use.

PARTS LIST			
A	TABLE TOP		1
B	TABLE LEG		4
C	BOLT(M8*35)		8
D	LOCK WASHER		8
E	METAL WASHER		8
F	PLASTIC BOLT CAP		8
G	HEX WRENCH		1

