

BRIXTON KNOBS & PULLS ~ 7 SIZES Matching Appliance Pulls - see page 188



Backplates can only be used with knobs

	AG	BLK	BSN	HB	PC	PN	SAB	UM
1/4" Rimmed Knob	TK880AG	TK880BLK	TK880BSN	TK880HB	TK880PC	TK880PN	TK880SAB	TK880UM
1/4" Ridged Knob	TK881AG	TK881BLK	TK881BSN	TK881HB	TK881PC	TK881PN	TK881SAB	TK881UM
1/4" Button Knob	TK882AG	TK882BLK	TK882BSN	TK882HB	TK882PC	TK882PN	TK882SAB	TK882UM
3/4" cc Pull	TK883AG	TK883BLK	TK883BSN	TK883HB	TK883PC	TK883PN	TK883SAB	TK883UM
5/16" cc Pull	TK884AG	TK884BLK	TK884BSN	TK884HB	TK884PC	TK884PN	TK884SAB	TK884UM
6 5/16" cc Pull	TK885AG	TK885BLK	TK885BSN	TK885HB	TK885PC	TK885PN	TK885SAB	TK885UM
7 7/16" cc Pull	TK886AG	TK886BLK	TK886BSN	TK886HB	TK886PC	TK886PN	TK886SAB	TK886UM
8 13/16" cc Pull	TK887AG	TK887BLK	TK887BSN	TK887HB	TK887PC	TK887PN	TK887SAB	TK887UM
12" cc Pull	TK888AG	TK888BLK	TK888BSN	TK888HB	TK888PC	TK888PN	TK888SAB	TK888UM
12" cc Appliance Pull	TK889AG	TK889BLK	TK889BSN	TK889HB	TK889PC	TK889PN	TK889SAB	TK889UM
1 3/8" Backplate	TK890AG	TK890BLK	TK890BSN	TK890HB	TK890PC	TK890PN	TK890SAB	TK890UM



Part Number is specific to shape and finish. cc = measurement center-to-center between the screw holes.
NOTE: For detailed dimensions such as overall length, height, base width, etc. see price list or visit TopKnobs.com.