

INSTALLATION MANUAL

1.



Clean the contact area on the wall with a wet cloth and ensure the it then is dry and free from dust.

2.



Tear off the protective film

3.




Compress drawbar of suction cup with hand, exhaust air from its chassis, fix its position

4.



Turn the suction cup to the right till it stops

5.



Install

Maximun load-bearing : 11LBS

Application: Suitable for use on smooth surface building material

Example: Glass, Smooth Tile, Smooth metal surface, PVC ,paint panel and so on

Reminder: Can not be used on the surface which is rough, or rugged, or with small cracks, or small cracks.

Example: Natural marble, Sanded glass, Stucco wall, Latex paint wall, wallpaper, Mosaic, Natural timber and so on