
## INSTRUCTIONMANUAL



# Pleasekeepthismanualandproductcodenumberforfuturereference andfororderingreplacementpartsifnecessary.

#### **GENERAL INSTRUCTIONS**

- Read this manual carefully and completely before proceeding.
- It is recommended that you wear safety glasses at all times during the installation.

#### **INSTALLATION OVER CERAMIC TILES**

- If your shower door is to be installed over ceramic tiles, the tiles should lay completely under the wall jamb.
- Silicone should be used to seal the gap where the ceramic tiles meet the fixed panel.


#### **NOTICE**

- Caulking : no sealant is required inside the shower, unless otherwise stated.
- Some models are equipped with clear sealing gaskets.


#### CARE FOR YOUR SHOWER DOOR

- Never use scouring powder pads or sharp instruments on metal pieces or glass panels.
  An occasional wiping down with a mild soap diluted in water is all that is needed to keep the panels andmetal parts looking new
- We recommend wiping the glass panels with a squeegee after each use.

### **Tools Required**



## Detailed Diagram of Shower Enclosure Components



NO.	Name	Picture	Qty	NO.	Name	Picture	Qty
1	Wall profile-A		1	9	Wall profile-B		1
2	Connector of support rail-A		1	10	Magnect strip		2
3	Fixed panel		1	11	screw ST4x30	<b>*</b>	8
4	Guide Rail		1	12	6mmWall plug		8
5	Bar-Fixed Panel Bracket		1	13	Back to back door pull		1
6	Hinges	B	2	14	Door seal	H	1
7	Moved glass		1	15	Anti-splash threshold	건	1
8	Connector of support rail-B		1	16	Door sweep	H	1

