

UTTERMOST LIGHTING

INSTALLATION INSTRUCTIONS:

PLEASE USE THE INFORMATION OUTLINED IN THIS SHEET FOR THE CEILING INSTALLATION PART OF YOUR FIXTURE ASSEMBLY.

1. BEFORE INSTALLING FIXTURE, CAREFULLY UNPACK AND IDENTIFY ALL PARTS REFERRING TO ILLUSTRATION FIGURE 1.

BE SURE THE POWER TO THE INSTALLATION POINT IS OFF.

2. WITH THE NIPPLE PROPERLY SITUATED.

PROCEED TO THREAD ONTO THE END OF THE NIPPLE PROTRUDING INTO THE OUTLET BOX.

3. MAKING THE CONNECTIONS:

PROCEED TO THREAD THE NIPPLE INTO THE BOTTOM CENTER.

AND TIGHTEN THE LOWER SET SCREW.

PROCEED TO THREAD LOCK NUT AND SHAKE PROOF WASHER UP NIPPLE UNTIL SEATED.

PROCEED TO ATTACH THE FIXTURE GROUND WIRE TO HOUSE GROUND WIRE USING WIRE CONNECTORS, USING WIRE CONNECTORS CONNECT THE HOUSE WHITE WIRE TO THE FIXTURE SUPPLY WIRE, CONNECT THE HOUSE BLACK WIRE TO THE FIXTURE SUPPLY WIRE.

FIGURE 1.

