

ASSEMBLY AND INSTALLATION INSTRUCTIONS

OD37396

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: Before installing, consult local electrical codes for wiring and grounding requirements.

Installation Steps:

1. Thread the two Headless Screws-1 to the Cross Bar, and then secure with four Lock Nuts. *(You can adjust the length of the screws if necessary.)*
2. Attach the Cross Bar to the Ceiling Box by using two Mounting Screws.
3. Attach the Loop onto the Nipple-1.
4. Choose a certain length of the Chain you need, and weave the Fixture Wire and the Grounding Wire through the Chain Links. Connect the Chain with the Loop by using the Loop Lock.
5. Connect the Chain with the Top Loop by using the Loop Lock.
6. Thread the Fixture Wire and Grounding Wire through the Top Loop and Canopy.
7. Make wire connections with Wire Nuts:
 - The smooth wire (w/ marking) from fixture to the black wire from power source.
 - The ridged wire (w/o marking) from fixture to the white wire from power source.
 - Attach the Grounding Wire and House Grounding Wire to the Cross Bar with a Green Grounding Screw. Carefully tuck wires back into the Ceiling Box.
8. Attach the Canopy to the Cross Bar by inserting two Headless Screws, and then secure with the Bolt Nuts-1.
9. Install a bulb. *(Please do not exceed the maximum capacity which is recommended on the package.)*
10. Twist the Finial onto the Nipple-2, thread the Nipple-2 into the hole on the bottom of the Glass Frame, and then secure with the Washer and Hex Nut.
11. Unscrew and remove the Screws on the Glass Frame. Place four Glass Shades into the Glass Frame carefully, and then secure them with Clips and Screws. (See Fig.1 and Fig.2)
12. Attach the Glass Frame upward the Dome by inserting the Headless Screws-2, and then secure with Rubber Pad and Bolt Nuts-2.
13. Turn on the power at fuse or circuit box.

