

ASSEMBLY AND INSTALLATION INSTRUCTIONS

C0080 / C0195

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTES: 1. Before installing, consult local electrical codes for wiring and grounding requirements.
2. READ AND SAVE THESE INSTRUCTIONS.

Hardware Package (included):



Mounting Strap (A)



Mounting Screw (B)




Green Grounding Screw (C)



Long Screw (D)



Lock Nut (E)



Wire Connector (F)



Ball Nut (G)



Finial (H)



Hex Nut (I)



Washer (J)



Threaded Pipe (K)




Rubber Pad (L)



Metal Pad (M)



Decorative Cup (N)



Installation Steps

Turn off the power at fuse or circuit box.


1. Thread the long screws through mounting strap, then secure them with two lock nuts. Adjust the length of long screws if necessary.
2. Attach the mounting strap to the outlet box by using two mounting screws.
3. Pull out the source wires from the outlet box. Make wire connections using wire connectors as follows:
 - Connect the smooth-coated wire (marked) from the fixture to the black wire from the power source.
 - Connect the ribbed-coated wire (unmarked) from the fixture to the white wire from the power source.
 - Attach the fixture grounding wire to the mounting strap with the green grounding screw, then connect it to the house grounding wire with a wire connector.
 Carefully put the wires back into the outlet box.
4. Attach the fixture to the mounting strap, and secure it with two ball nuts.
5. Attach threaded pipe to the coupling of the socket, and secure it with a washer and hex nut.
NOTE: Depth of threaded pipe may need to be adjusted to properly fit glass shade, decorative cup and finial.
6. Install bulbs (not included). See relamping label at socket area or packaging for maximum allowed wattage.
7. Attach the glass shade to the ceiling pan by inserting the threaded pipe, then secure it with a metal pad, rubber pad and hex nut.

8. Slip the decorative cup up through the threaded pipe, secure it with a finial.


Turn on the power at fuse or circuit box.

The following parts are available for re-order if damaged or missing.


Spare Parts List:



Assembly Kit
5292MM (1 SET) for C0080
5957MM (1 SET) for C0195



Glass Shade
9702AB (1PC) for C0080
10015EW (1PC) for C0195



A: 16-1/4"

B: 13-3/4"