


# ASSEMBLY AND INSTALLATION INSTRUCTIONS

H0226

**WARNING:** TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

**NOTES:** 1. Before installing, consult local electrical codes for wiring and grounding requirements.  
2. Read and save these instructions.

## Hardware Package (Included):




## Installation Steps

Turn off the power at fuse or circuit box


1. Attach two fixture mounting screws to the mounting strap, and then secure it with two lock nuts. Adjust the length of the fixture mounting screws if necessary.
2. Attach the mounting strap to the outlet box using two mounting screws.
3. Rod Connections:
  - a. Thread the fixture wire from the fixture through the lower rod, and then secure the lower rod onto fixture using the threaded pipe.
  - b. Thread the fixture wire through the middle rod, and then secure the middle rod onto the lower rod using the threaded pipe.
  - c. Thread the fixture wire through the upper rod, and then secure the upper rod onto the middle rod using the threaded pipe.

Note: Length adjustable from 33-1/2" to 84-1/2"H.  
Use fewer rods if shorter length is desired.
4. Pull out the source wires from the outlet box. Make wire connections using wire connectors as follows:
  - Connect the smooth-coated wire (marked) from the fixture to the black wire from the power source.
  - Connect the ribbed-coated wire (marked) from the fixture to the white wire from the power source.
  - Attach the fixture grounding wire to the mounting strap with the green grounding screw, and then connect it to the house grounding wire with a wire connector.

Carefully put the wires back into the outlet box.
5. Attach the canopy onto the mounting strap and tighten it with two ball nuts.



6. Install the crystal on the frame (J).
7. Attach the frame (J) with screw (I) (included) to the lamp body by "L" screwdriver (H).  
Adjust to the right and if necessary.
8. Install nine G9 Xenon Bulbs Max.40W (included).  
Check relamping lable at socket area or packaging for maximum allowed wattage.
9. Angled mounting recommended for a vaulted or angled ceiling. (See Fig. 1)




**Turn on the power at fuse or circuit box**

The following parts are available for re-order if damaged or missing.

**Spare Parts List:**

Mounting Strap (A)	Mounting Screw (B)	Wire Connector (C)	Fixture Mounting Screw (D)	← Assembly Kit 6038MM (1SET)		
Green Grounding Screw (E)	Lock Nut (F)	Ball Nut (G)	Screwdriver (H)			
12"Rod 3179RD(3PCS)	6"Rod 3180RD(1PC)	3"Rod 3181RD(1PC)				



**A: 29"W**  
**B: 33.5"- 84.5 "H**