
ASSEMBLY AND INSTALLATION INSTRUCTIONS

T0042

WARNING: BE SURE TO SHUT OFF POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: 1. Before installing, consult local electrical codes for wiring and grounding requirements.

2. READ AND SAVE THESE INSTRUCTIONS.



- 6. Choose the length of the chain you need, then weave the fixture wire and the fixture grounding wire through the chain, collar and canopy.
- 7. Connect one end of the chain with the loop by using a loop lock.

panels.


- 8. Connect the other end of the chain with the top loop by using another loop lock.
- 9. Thread the fixture wire and fixture grounding wire through the top loop, nipple and mounting strap.
- 10. Pull out the outlet wires and house grounding wire from the outlet box. Make wire connections using the wire nuts:

- ---The smooth wire (marked) from the fixture to the black wire from the power source.
- ---The ridged wire (unmarked) from the fixture to the white wire from the power source.
- ---Attach the fixture grounding wire to the mounting strap with the green grounding screw. Then connect it to the house grounding wire with a wire nut.

Carefully put the wires back into the outlet box.

- 11. Attach the canopy to the mounting strap by inserting the top loop, then secure it with the collar.

 CAUTION: With silicone caulking compound, caulk completely around where back of canopy meets with the ceiling surface to prevent water from seeping into the outlet box.
- 12. Turn on the power at the main fuse or circuit breaker box.



A: 14-7/8"

B: 6"

