



WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING * SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Loosen set screws (L) from top of nipple (N), and remove metal frame (Q).
2. To insert glass panels (O) to the metal frame (Q). Make sure metal tabs (P) are flipped up. To secure glass panels by bending back metal tabs (P) downwards. Hook assembly part (M) to inner of handle cap. (See left illustration)
3. Attach metal frame (Q) to handle cap, letting nipples (N) pass through the holes on handle cap and secure with set screws (L).
4. Hook sleeve (J) to assembly part (K). (See left illustration) Attach chain (G) to top loop (H) by opening I closing end link of chain.
5. Unscrewing the canopy ring (F) from chain mounting loop (E) and slide canopy (D) and canopy ring (F) on chain.
6. Feed wire through chain (G), mounting loop (E), canopy (D) and nipple (B). Attach mounting strap (A) to ceiling outlet box using mounting screws (C) provided.
7. Insert threaded nipple (B) in mounting strap (A). Using pliers, thread one of hex nut to nipple (B) to secure. Attach chain mounting loop (E) to thread nipple using the ceiling loop screw.
8. Open the end link of chain and screw chain mounting loop (E) to the nipple using set screw and hook the chain (G) to mounting loop (E) by closing the end cut link.
9. Attach the ground wire (silver or brass in color) from the fixture to the ground junction box wire (usually green or copper wire). Fasten together with a plastic wire connector and wrap the connection with electrical tape. Be sure no wire strands are exposed. It is imperative that the outlet box in your home be properly grounded. Be sure no wire strands are exposed.
10. Connect the neutral wire from the fixture (ridges molded wire) to the neutral wire from the junction box (usually white). Fasten together with a plastic wire connector and wrap the connection with electrical tape. Be sure no wire strands are exposed.
11. Connect the hot wire from the fixture (smooth wire) to the hot wire (usually black) from the junction box. Fasten each together with a plastic wire connector and wrap the connection with electrical tape. Be sure that no wire strands are exposed. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OTHERWISE SAFETY WILL BE COMPROMISED.
12. Tuck wire connection neatly into ceiling outlet box. Slip canopy (D) to ceiling and secure with threaded canopy ring (F). Insert light bulbs into the sockets.