

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

- 1. Insert light bulb (not included) into socket.
- 2. Remove protective plastic (D) from electrical plug (C).
- 3. Plug lamp into wall outlet.
- 4. ADJUSTMENT INSTRUCTION:
 - 1. Loosen adjustment key (B).
 - 2. Adjust lamp by swing lamp arm (A) or lamp shade to desired position.
 - 3. Tighten the adjustment key (B).