

NEVIS OUTDOOR LARGE FLOOR LAMP

700OPRTNEV92762

General Product Information



Safety Information

For use only on GFCI protected circuits.

CAUTION: RISK OF ELECTRIC SHOCK

Do not use extension cord near water or where water may accumulate. Keep lamp at least 16 feet from pools and spas. Keep plugs and receptacles dry.



Turn off electrical current at the source before working with any lighting fixture or portable lamp. Install and use this product in adherence with local electrical codes and regulations.


WARNING: When using outdoor use portable luminaires, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following:

- Use only three-wire outdoor extension cords that have three-prong grounding plugs and grounding receptacles that accept the appliance's plug.
- Ground Fault Circuit Interrupter (GFCI) protection is to be provided on the circuit(s) or outlet(s) to be used for the wet location portable luminaire. Receptacles are available having built-in GFCI protection and are able to be used for this measure of safety.
- Use only with an extension cord for outdoor use, such as an extension cord of cord type SEW, SEOW, SEOWW, SOW, SOOW, STW, STOW, STOOW, SJEW, SJEOW, SJEOOW, SJW, SJOW, SJOOOW, SJTW, SJTOW, or SJTOOW. READ ALL INSTRUCTIONS. SAVE THESE INSTRUCTIONS.



FIXTURE PARTS

- A. Finial
- B. Shade
- C. Integrated LED Lamp Assembly
- D. Stem
- E. On/Off Light Switch
- F. Lamp Base
- G. Power Cord



INSTRUCTIONS

1. Place the shade on top of the LED lamp assembly and secure it with the finial.
2. Plug the lamp into a working electrical socket.
3. Use the light switch to turn the lamp on/off to test for proper functioning.