

## **FEATURING**



## TimeSavor™ system

The TimeSavor™ system's Frozen Bake Technology allows you to skip preheating for favorites like pizza, lasagna, chicken nuggets, fries or pies so you can cook frozen foods faster.



## HeatRight<sup>™</sup> system

The HeatRight™ system's True convection helps you to cook food faster" with a rear fan and third heating element to circulate hot air over, under, and around food.



## QuickSelect<sup>™</sup> system

The QuickSelect™ system's FlexHeat™ triple radiant element is like having three elements in one. A 6" inner ring is great for smaller pots and pans, while 9" and 12" outer rings make room to heat larger cookware.

# Every day, care.

## Double Oven Electric Ranges





#### Available colors



Stainless Steel



White Ice



Black Ice

#### PRODUCT DIMENSIONS



- A. 35³/=" ± ¹/s" (90.8 cm ± 0.3 cm) cooktop height (minimum) with leveling legs screwed all the way in\*
- panel)\*\*

  C. 47'/s" ± '/s" (119.7 cm ± 0.3 cm)
  overall height (minimum) with
  leveling legs screwed all the
  way in\*
- Range can be raised approximately 1" (2.5 cm) by adjusting the leveling legs.

D. 28<sup>1</sup>/<sub>2</sub>" ± <sup>1</sup>/<sub>4</sub>" (72.4 cm ± 0.6 cm) depth with handle

depth with handle E. 26<sup>1</sup>/s" ± <sup>1</sup>/s" (66.4 cm ± 0.3 cm)\*\*\*

F. 29<sup>15</sup>/16" ± <sup>1</sup>/16" (76.0 cm ± 0.2 cm) width


- \*\* Model/serial/rating plates may be rotated up from behind the control panel for viewing from the front of the range.
- \* Excludes handle. Dimension given is from wall to front of oven door and will vary based on electric outlet receptacle installation.

#### CABINET OPENING DIMENSIONS

Cabinet opening dimensions shown are for: 25" (63.5 cm) countertop depth, 24" (61 cm) base cabinet depth, and 36" (91.4 cm) countertop height

IMPORTANT: If installing a range hood or microwave hood combination above the range, follow the range hood or microwave hood combination installation instructions for dimensional clearances above the cooktop

A freestanding range may be installed next to combustible walls with zero clearance.



- 18" (45.7 cm) upper cabinet to countertop
- 13" (3.0. orn) upper caumer to countertop 13" (7.0. orn) upper cabinet depth 30" (76.2 cm) min. opening width For minimum clearance to the top of the cooktop, see NOTE. 30" (76.2 cm) min. opening width
- Cabinet door or hinge should not extend into cutout\*
  11/s" (3.8 cm) min. from right side cabinet
  2" (5.1 cm) min. from floor
  7" (17.8 cm) min. from floor

- J. 8" (20.3 cm) width K. 3 " (8.91 cm) min. from floor
- Proper positioning of outlet shown above
- \* Nothing located in shaded areas can extend more than 11/2" (3.8 cm) from wall or range will not slide all the way back.

NOTE: 24" (61.0 cm) minimum when bottom of wood or metal cabinet is covered by not less than 1/4" (0.64 cm) flame retardant millboard covered with not less than No. 28 MGS sheet steel, 0.015" (0.4 mm) stainless steel, 0.024" (0.6 mm) aluminum or 0.020" (0.5 mm) copper.

30" (76.2 cm) minimum clearance between the top of the cooking platform and the bottom of an uncovered wood or metal cabinet.

## WGE745C0F

## 30" Freestanding Range - 6.7 cu. ft.



### TimeSavor<sup>™</sup>system

Frozen Bake<sup>™</sup> Technology



#### HeatRight<sup>™</sup> system

- True Convection
- Convection Conversion
- Temperature Sensor



#### QuickSelect™ system

- FlexHeat<sup>™</sup> Triple Radiant Element
- FlexHeat<sup>™</sup> Dual Radiant Element



#### ReadySet<sup>™</sup> system

- Rapid Preheat
- Keep Warm
- Delay Cook
- Warm Zone Element



#### CompleteClean system

- Steam Clean
- Adjustable Self Clean
- Easy Wipe Ceramic Glass Cooktop
- Dishwasher-safe knobs

# **ACCESSORIES & REPLACEMENT PARTS**

- Part number 8273888A Anti-Tip Kit for Range
- Part number PT220 4' 3-Wire 40 amp Range Cord
- Part number PT400 4' 4-Wire 40 amp Range Cord
- Part number PT600 6' 4-Wire 40 amp Range Cord
- Part number 8171394RC 4' 4-Wire 40 amp Power Cord
- Part number 8171385RC 4' 3-Wire 40 amp Power Cord
- Part number 4378577 Brick Baking Stone
- Part number 4396923 Porcelain Broiler Pan & Grid
- Part number W10123240 Premium Broil Pan & Roasting Rack
- Part number 8009 Appliance Light Bulb 40 Watt

