

LAMP ASSEMBLY INSTRUCTIONS

ITEM NO: 728FL

1. Unpack the lamp from carton carefully.
adjust the angle of arm.
Adjust the height of the light
2. Place shade (N) over sockets (M),
and secure with socket rings (O)

WARNING:

1. Use MAX.60W type A bulb (not included) for the Table
2. Do not use polishes or cleaners on your lamp.
JUST WIPE CLEAN WITH SOFT CLOTH.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

