

Genoa Collection Installation Instructions

Prior to Installation

Genoa Collection tiles have a TCNA variation rating of V1.

Cutting

All cutting must be performed on a suitable wet saw with a new blade appropriate for the material. Tile nips cannot be used.

Substrate

All tile products must be installed over a substrate suitable to the installation location. Refer to current TCNA installation guidelines for suitable substrate materials and preparation.

Adhesive Installation

All glass field tile products must be installed using a suitable mastic for wall installations. Refer to the current TCNA handbook for the appropriate adhesives and trowel methods for your particular installation.

Sealing

Glass field tile grout needs to be sealed with a high-quality grout sealer after grout has dried completely. It is not necessary to apply sealer polished glass tile.

Grout

Grout color to be specified by designer/product specifier. Grout joint widths on field tiles to be specified by the designer/product specifier. Unsanded grout should be used on all glass tile. Refer to current TCNA installation guidelines for minimum/maximum grout joint widths depending on type of grout used. Fully-installed and grouted material must be sealed per TCNA guidelines.

Limitations of Liability

Medici & Co. is not responsible for any installation and cannot replace materials due to improper installation.

Warranty

Installer to inspect all materials upon receipt and submit to the designer/product specifier, through photographs or in-person inspection, examples of the tile range for approval. Written approval of materials must be received by Medici & Co., either by mail or email (info@mediciandco.com), within 15 days of receipt of materials. Special-order and/or custom materials are not returnable unless a physical manufacturing defect is present. No returns or warranty claims may be submitted on any installed product or uninstalled product outside the specified warranty return period.